# **OWNER'S MANUAL 2011**

## 990 Supermoto R USA





# DEAR KTM CUSTOMER

Congratulations on your decision to purchase a KTM motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it accordingly.

We wish you a lot of enjoyment in riding this vehicle.

Please enter the serial numbers of your vehicle below.

Chassis number/type label (  p. 26)	Dealer's stamp
Engine number (🕶 p. 28)	
Key number (🖤 p. 27)	

The owner's manual contained the latest information for this model at the time of going to print. However, it is never possible to exclude small deviations arising from further development in design and construction.

All specifications are non-binding. KTM Sportmotorcycle AG specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not form part of the regular scope of delivery.

# DEAR KTM CUSTOMER

© 2010 KTM-Sportmotorcycle AG, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061) According to the international quality management standard ISO 9001, KTM uses quality assurance processes that lead to the maximum possible quality of the products. Issued by: TÜV Management Service

KTM-Sportmotorcycle AG 5230 Mattighofen, Austria

MEANS OF REPRESENTATION	. 7
IMPORTANT INFORMATION	. 8
Overview of labels	12
VIEW OF VEHICLE	22
View of vehicle, front left side (vehicle differs slightly from	
photo)	22
View of vehicle, rear right side (vehicle differs slightly from	
photo)	
SERIAL NUMBERS	
Chassis number/type label	
Key number	27
Engine number	28
Fork part number	28
Shock absorber part number	
CONTROLS	30
Clutch lever	30
Hand brake lever	30
Throttle grip	31
Light switch	31
Headlight flasher switch	32
Turn signal switch	32
Horn button	
Ignition/steering lock	33
Immobilizer	34
Emergency OFF switch	34
Electric starter button	35
Combination instrument	35
Combination instrument - function buttons	36
Combination instrument - tachometer	36

Combination instrument - indicator lamps	37
Combination instrument - display	38
Combination instrument - speedometer	39
Setting kilometers or miles	39
Combination instrument - time	40
Setting the clock	40
Combination instrument - ODO display	41
Combination instrument - setting/resetting TRIP 1	41
Combination instrument - setting/resetting TRIP 2	42
Combination instrument - TRIP F display	43
Combination instrument - ambient temperature display	43
Setting the temperature units	44
Combination instrument - warning of slippery roads	44
Combination instrument - coolant temperature indicator	45
Opening the filler cap	
Closing the filler cap	46
Handrails	47
Seat lock	
Tool set	48
Helmet lock	
Passenger footrests	
Shift lever	
Foot brake lever	50
Side stand	
PREPARING FOR USE	52
Information on first use	
Running in the engine	
Loading the vehicle	53

RIDING INSTRUCTIONS	56	
Checks and maintenance measures when preparing for		
use	56	
Starting	57	
Starting off	58	
Shifting, riding	59	
Braking	62	
Stopping, parking	63	
Refueling	65	
SERVICE SCHEDULE	67	
Service schedule	67	
TUNING THE CHASSIS	70	
Fork/shock absorber	70	B
Adjusting the compression damping of the fork	70	
Adjusting the rebound damping of the fork	71	
Adjusting the spring preload of the fork	72	
Compression damping of the shock absorber	74	
Adjusting the low-speed compression damping of the shock		
absorber	74	
Adjusting the high-speed compression damping of the		
shock absorber		
Adjusting the rebound damping of the shock absorber		
Adjusting the spring preload of the shock absorber 🔌		
SERVICE WORK ON THE CHASSIS	79	
Raising the motorcycle with the front wheel stand		w
Taking the motorcycle off of the front wheel stand	79	••
Raising the motorcycle with the rear wheel stand	80	
Taking the motorcycle off of the rear wheel stand	80	
Bleeding the fork legs	81	

Removing the seat	81
Mounting the seat	82
Mounting the helmet lock on the vehicle	82
Reinstalling the fuel tank	83
Positioning the fuel tank	84
Checking the chain for dirt	86
Cleaning the chain	86
Checking the chain tension	87
Adjusting the chain tension	88
Checking the chain, rear sprocket and engine sprocket	90
Adjusting the basic position of the clutch lever	92
Checking/rectifying the fluid level of the hydraulic clutch	93
RAKES	94
Adjusting the basic position of the hand brake lever	94
Checking the front brake discs	
Checking the front brake fluid level	95
Adding front brake fluid 🔌	96
Brake linings	97
Checking the front brake linings	97
Checking the free travel of the foot brake lever	98
Checking the rear brake disc	
Checking the rear brake fluid level 1	
Adding rear brake fluid 🔌 1	.01
5 5	.02
,	.04
Removing the front wheel 🔌 1	.04
Installing the front wheel 🔌 1	.05
Removing the rear wheel 🔌 1	.07
Installing the rear wheel 🌂 1	

Checking rear hub shock absorbers 🔌	109
Checking the tire condition	110
Checking the tire air pressure	
ELECTRICAL SYSTEM	114
Removing the battery 🔌	114
Installing the battery 🔌	115
Recharging the battery 🔌	116
Changing the main fuse	118
Changing the fuses of individual power consumers	120
Changing the headlight bulb	122
Changing the parking light bulb	124
Changing the turn signal bulb	127
Changing the brake light bulb	128
Changing the tail light bulbs	132
Changing the license plate lamp	136
Checking the headlight setting	137
Adjusting headlight range	138
Activating/deactivating the ignition key	138
COOLING SYSTEM	143
Cooling system	
Checking the antifreeze and coolant level	143
Checking the coolant level in the compensating tank	
Draining the coolant 🔌	147
Filling/bleeding the cooling system 🔌	148
TUNING THE ENGINE	151
Checking the play in the throttle cable	151
Adjusting the play in the throttle cable 🔌	152
Ignition curve plug-in connector	152
Adjusting the ignition curve to the fuel quality	153


Checking the basic position of the shift lever	153
Adjusting the basic position of the shift lever 🔌	154
SERVICE WORK ON THE ENGINE	155
Checking the engine oil level	155
Changing the engine oil and filter, cleaning the oil	
screens 🔌	156
Draining the engine oil and filter, cleaning the oil screens	156
Filling up with engine oil	161
Adding engine oil	162
CLEANING, CARE	163
Cleaning motorcycle	163
Protective treatment for winter operation	165
STORAGE	166
Storage	166
Preparing for use after storage	167
TROUBLESHOOTING	168
IMMOBILIZER BLINK CODE	171
ENGINE CONTROL BLINK CODE	173
TECHNICAL DATA - ENGINE	179
Capacity- engine oil	180
Capacity - coolant	180
TECHNICAL DATA - ENGINE TIGHTENING TORQUES	181
TECHNICAL DATA - CHASSIS	185
Lighting equipment	186
Tires	187
Capacity - fuel	187
TECHNICAL DATA - FORK	188
TECHNICAL DATA - SHOCK ABSORBER	189

TECHNICAL DATA - CHASSIS TIGHTENING TORQUES	191
SUBSTANCES	194
AUXILIARY SUBSTANCES	198
STANDARDS	200
INDEX	201

# **MEANS OF REPRESENTATION**

#### Symbols used

The meaning of specific symbols is described below.



The typographical formats used in this document are explained below.

Specific name	Identifies a proprietary name.
Name®	Identifies a protected name.
Brand™	Identifies a brand available on the open market.

7

#### **Use definition**

KTM sport motorcycles are designed and constructed to meet the normal demands of regular road operation but not for use on race courses or offroad.

### Info

The motorcycle is authorized for public road traffic in the homologous version only.

### Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care and tuning work on the engine and chassis are properly carried out as described in the owner's manual. Poor adjustment and tuning of the engine and suspension can lead to damage and breakage of components.

Using the motorcycle in extreme conditions such as very muddy or wet roads can lead to above-average wear of components such as the transmission train or the brakes. For this reason, it may be necessary to service or replace worn parts before the limit specified in the service schedule is reached.

Pay careful attention to the prescribed running-in period and service intervals. Close adherence to these periods will significantly lengthen the service life of your motorcycle.

### Warranty

The work prescribed in the service schedule must be carried out by an authorized KTM workshop only and confirmed in the customer's service record and in the **KTM dealer.net**; otherwise, all warranty claims will be void. No warranty claim can be honored for damage result-ing from manipulation and/or other changes to the vehicle.

#### Fuels, oils, etc.

The fuels and lubricants named in the owner's manual must be used according to specifications.

### Spare parts, accessories

For your own safety, only use spare parts and accessory products that have been approved and/or recommended by KTM and have them installed by an authorized KTM workshop. KTM accepts no liability for other products and any resulting damage. Some of the spare parts and accessory products are specified in parentheses under the respective descriptions. Your KTM dealer will be glad to advise you.

You will find the current **KTM PowerParts** for your vehicle on the KTM website. International KTM Website: http://www.ktm.com

### Work rules

Special tools are necessary for some of the work. These are not included with the vehicle and can be ordered under the number in parentheses. Ex: valve spring mounter (59029019000)

During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.

Where thread lockers are used on screw connections (e.g., Loctite®), follow the instructions for use from the manufacturer.

Parts that you want to reuse following repairs and servicing should be cleaned and checked for damage and wear. Change damaged or worn parts.

Following repairs or servicing, the vehicle must be checked for roadworthiness.

#### **Transport**

#### Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

#### Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being
run. Always let the vehicle cool first.

- Switch off the engine and remove the ignition key.
- Secure the motorcycle against falling over or rolling away using straps or other suitable devices.

### Environment


Motorcycling is a wonderful sport and we naturally hope that you can enjoy it to the full. However, it can also lead to problems with the environment and conflict with other persons. Responsible behavior in handling the motorcycle can help to avoid such problems and conflicts. To protect the future of motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

10

\_\_\_\_\_

11

### **Overview of labels**



1	Information on emission control
2	Type label, Canada
3	Information on operating substances and tires
4	Information on noise emission
5	Information on preparing for use
6	Information on the fuel evaporation system
7	Information on chain tension
7	Information on suspension setting
8	Type label, USA

	VEHICLE EMISSION	CONTROL INFORMAT	ION
	NUFACTURER: KTM SP		G - Mattighofen, Austria Milian Ave, Amherst, OH 44001
ENGINE DISPLACEMEN ENGINE FAMILY PERMEATION FAMILY	IT 999 cc BKTXC.999SPR BKTXPP104RK1	2 TWO	EMISSION CONTROL SYSTEM 2, PAIR, TBI, HO2S 990 SUPERMOTO R
THIS VEHICLE CON		ND CALIFORNIA REGU	JLATIONS APPLICABLE TO
	NOX, 12.0 G/KM CO EXHA		
ENGINE TUNEUP SPEC			
IGNITION TIMING	NON ADJUS		
IDLE SPEED :	1450 RPM IN		
IDLE MIXTURE :	NON ADJUS		
VALVE CLEARANCE :	0.10 - 0.15 IN		HAUST
SPARK PLUG :	NGK LKAR8BI	9	
SPARK PLUG GAP :	0,8 mm		
FUEL :	UNLEADED	GASOLINE ONLY - 91	(R+M)/2 OCTANE OR HIGHER
OL:	SAE 10 W 60		
VI.N.: VBKx	xxxxxXMxxxxxx	DATE OF MA	NUFACTURE: XX.XX.XXXX

Information on emission control

MANUFACTURED BY/FABRIOUE PAR:		KTM SPORTMOTORCYCLE AG					
GVWR	PNOV:	400	KG	DATE:			
VINA	U.V.:	VBKx	******				
TYPE:		MC					
G	awr/PNE	DE	TIRE/PNEU-DI	MENSION-RIMUWITE	the second se	INFL. PRESS. E GONFL. À FROID KPA	
1st	169	KG	120/70-17	3.50-17	31	220	
2nd	250	KG	189/55-17	5.50-17	31	220	1
SAF	ETY REG	ULATION ES NOR	AS IN EFFECT ON T	PLICABLE STANDARDS F THE DATE OF MANUFACT APPLICABLES EN VERT DU CANADA EN VIGUEUR	TURE - CE VÉHICI U DU RÉGLEMEN	ULE EST CONFORME T SUR LA SÉCURITÉ	600962-01

Type label, Canada

990 SUPERMO	ото	626.03.099.000	
Fuel :	RON95 unleade	d (USA = PREMIUM PON 91)	
Tyre front :	120/70-17, spee	d index ZR	
Air pressure front :	rider only	2.2 bar (31 psi)	
	max. payload	2.4 bar (34 psi)	
Tyre rear :	180/55-17, spee	d index ZR	
Air pressure rear :			
	max. payload	2.5 bar (35 psi)	
Max. payload :	195 kg (430 lbs)	, max. total weight 400 kg (882 lbs)	
Engine oil :	fully syntetic 10	W/50 (5W/40 under 0°C, 32°F)	
Furthe	r information s	see owners handbook	600969-01

Information on operating substances and tires

14

### MOTORCYCLE NOISE EMISSION CONTROL INFORMATION KTM SPORTMOTORCYCLE AG, AUSTRIA THIS 2011 KTMB210999 MOTORCYCLE 626.05.182.000 AND 626.05.183.000 MEETS U.S. EPA NOISE EMISSION REQUIREMENTS OF 80 dBA AT 4250 RPM BY THE U.S. FEDERAL TEST PROCEDURE. MODIFICATIONS WHICH CAUSE THIS MOTORCYCLE TO EXCEED FEDERAL NOISE STANDARDS ARE PROHIBITED BY U.S. FEDERAL LAW. SEE OWNER'S MANUAL.

Motorcycle Type : 990 SUPERMOTO R Date manufactured : xxxx xx xx VIN. : VBKXXX40XXMXXXXXX 101178-01

#### Information on noise emission

#### ACHTUNG

Lesen Sie vor der ersten Inbetriebnahme des Fahrzeuges die gesamte Bedienungsanleitung aufmerksam durch!

#### IMPORTANT

Please read the entire owner's manual carefully before putting the vehicle into operation for the first time.


#### ATTENZIONE


Prima della messa in funzione iniziale del veicolo, leggere con attenzione l'intero manuale d'uso!

ATTENTION

Lire attentivement l'ensemble du manuel d'utilisation avant de mettre le véhicule en service!

ATENCIÓN Lea completa y atentamente el manual de instrucciones antes de poner en servicio por primera vez el vehículo 600961-01 Information on preparing for use





Information on the fuel evaporation system

Information on chain tension

Information on suspension setting

990 SUPERMOTO R 626.01 199.000	1	FORK		SHOCK				
SETTING	Compression	Retound	Spring pretown (hume clackowne)	Compression knw speed	Compression high speed	Rehound	Spring pretoad (mer)	
Comfort	20	20	5	25	2	20	11	
Basic setting	15	15	5	20	1,5	15	11	
Sport (or > 90kg)	10	10	7	15	1	10	11	
Max. payload	10	10	7	15	1	10	13	600967-01

600966-01

NTER N	AFD. BY KTM SPO	ORTMOTORCYCLE AG	AUSTRIA	
SPORTHOTORCYCLES	M	DTORCYCLE	DATE	
GVWR	882 lbs	400 kg		
GAWR FRONT	353 lbs	160 kg WITH 120/70-	17 TIRE, 58W TYPE,	
	3,50-17 RIM, AT	31 psi 2,2 bar COL	.D	
GAWR REAR	551 lbs	250 kg WITH 180/55-	17 TIRE, 73W TYPE,	
	5,50-17 RIM, AT	31 psi 2,2 bar COL	.D	
THIS VEHICLE C	ONFORMS TO ALL	APPLICABLE U.S. FEDER	AL MOTOR VEHICLE	
SAFETY STAND	ARDS IN EFFECT O	N THE DATE OF MANUFAC	TURE SHOWN ABOVE.	
	VBK	xxxxxMxxxxxx		600963-01

Type label, USA

### **Notes/warnings**

Pay close attention to the notes/warnings.

#### lnfo

Various information and warning labels are affixed to the vehicle. Do not remove information/warning labels. If they are missing, you or others may not recognize potential hazards and may therefore be injured.

17

### **Grades of risks**



#### Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



#### Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



#### Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

#### Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



#### Warning

Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

#### **Owner's manual**

- Be sure to read this owner's manual carefully and completely before taking your first ride. It contains useful information and tips to help you operate and handle your motorcycle. Only then will you find out how to best customize the motorcycle for your own use and how you can protect yourself from injury. The owner's manual also contains important information on servicing the motorcycle.
- The owner's manual is an important component of the motorcycle and should be handed over to the new owner if the vehicle is sold.

#### **Reporting safety defects**

If you believe that your vehicle has a defect which could cause an accident resulting in injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying KTM North America, Inc.

If NHTSA receives similar complaints, it may open an investigation. If it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or KTM North America, Inc.

To contact NHTSA, you may either call the Vehicle Safety Hotline toll-free at 1–888–327–4236 or visit the website www.nhtsa.dot.gov, or write to: NHTSA Headquarters, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590. You can also obtain other information about motor vehicle safety from the Hotline.

#### Noise emission warranty

KTM Sportmotorcycle AG warrants that this exhaust system, at the time of sale, meets all applicable U.S. EPA Federal noise standards. This warranty extends to the first person who buys this exhaust system for purposes other than resale, and to all subsequent buyers. Warranty claims should be directed to: KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA Phone: (440) 985–3553 www.ktmusa.com KTM Canada, Inc., Customer Support, 1375-1 Marie-Victorin, Saint-Bruno, QC J3V 6B7 Phone: (450) 441–4451 x 4250 www.ktmcanada.com

### **Tampering warning**

It is not permitted to make changes to the components of the noise damping system. Federal law prohibits the following acts or causing thereof:

- 1 The removal or rendering inoperative other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 The use of the vehicle after such device or element of design has been removed or rendered inoperative.

Among those acts presumed to constitute tampering are the acts listed below.

- 1 Removal or puncturing of the muffler, baffles, header pipes or any other component which conducts exhaust gases.
- 2 Removal or puncturing of any part of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing any moving parts of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

#### **Operating noise warning**

This product should be checked for repair or replacement of parts if the motorcycle noise has increased significantly through use. Otherwise, the owner may become subject to penalties according to the applicable laws and regulations.

#### **Consumer rights**


Warranty claims should be submitted to an authorized KTM workshop. If you are not satisfied, please contact: KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA Phone: (440) 985–3553 www.ktmusa.com KTM Canada, Inc., Customer Support, 1375-1 Marie-Victorin, Saint-Bruno, QC J3V 6B7 Phone: (450) 441–4451 x 4250 www.ktmcanada.com Your rights may vary under national and regional laws.

View of vehicle, front left side (vehicle differs slightly from photo)




1	Combination instrument (* p. 35)
2	Rear mirror
3	Clutch lever (* p. 30)
4	Seat
5	Handrails (🕈 p. 47)
6	Level viewer, engine oil
7	Shift lever (
8	Engine number (🕶 p. 28)
9	Compression damping of the shock absorber (* p. 74)

### View of vehicle, rear right side (vehicle differs slightly from photo)




1	Seat lock (* p. 47)
2	Light switch (     p. 31)
2	Headlight flasher switch (* p. 32)
2	Turn signal switch (🕶 p. 32)
2	Horn button (* p. 33)
3	Filler cap
4	Emergency OFF switch (
4	Electric starter button (🕶 p. 35)
5	Hand brake lever (* p. 30)
6	Fork rebound setting and spring preload setting
7	Shock absorber rebound adjustment
8	Passenger footrests (* p. 49)
9	Foot brake lever (🖤 p. 50)
10	Chassis number/type label (* p. 26)
11	Fork compression adjustment

### Chassis number/type label




Chassis number **1** is embossed in the steering head at the right.

The type label for the USA **2** is fitted on the frame tube on the right.



### Key number



The type label for Canada 3 is fitted on the frame tube on the left.


## The **Code number** • key number can be found on the **KEYCODECARD**.

#### Info

You need the key number to order a spare key. Keep the  $\ensuremath{\text{KEYCODECARD}}$  in a safe place.


Use the orange programming key to activate and deactivate the black ignition key. Keep the orange programming key in a safe place: it must only be used for learning and programming functions.

### **Engine number**



The engine number  $\bullet$  is stamped on the left side of the engine under the engine sprocket.

### Fork part number




The fork part number **1** is stamped on the inner side of the fork stub.

### Shock absorber part number




The shock absorber part number  ${\bf 0}$  is stamped on the top of the shock absorber above the adjusting ring on the engine side.

#### **Clutch lever**



The clutch lever  $\bullet$  is fitted on the left side of the handlebar. The clutch is hydraulically operated and self-adjusting.

### Hand brake lever



The hand brake lever  $\bullet$  is fitted on the right side of the handlebar. The front brake is engaged using the hand brake lever.

### Throttle grip



The throttle grip  $\bullet$  is fitted on the right side of the handlebar.

### Light switch




The light switch **1** is fitted on the left side of the handlebar.

#### Possible states

≣D	Low beam on – The light switch is turned downwards. In this position, the low beam and tail light are switched on.
≣D	High beam on – The light switch is turned upwards. In this position, the high beam and tail light are switched on.

### Headlight flasher switch



The headlight flasher switch **1** is fitted on the left side of the handlebar.

#### **Possible states**

- Headlight flasher switch in basic position
- Headlight flasher switch pressed The headlight flasher switch (high beam) is operated in this position.

### **Turn signal switch**



The turn signal switch **1** is fitted on the left side of the handlebar.

#### **Possible states**

	Turn signal off
<b>令</b>	Left turn signal on – The turn signal switch is pressed to the left. The turn signal switch automatically returns to the central position after use.
₽	Right turn signal on – The turn signal switch is pressed to the right. The turn signal switch automatically returns to the central position after use.

To switch off the turn signal, press the turn signal switch towards the switch case.

### Horn button




The horn button  $\bullet$  is fitted on the left side of the handlebar.

#### **Possible states**

- Horn button  $\bowtie$  in basic position
- Horn button *▶* pressed The horn is operated in this position.

### Ignition/steering lock



The ignition/steering lock is in front of the upper triple clamp.


#### • Info The

The ignition may only be switched on using a black ignition key. Use the orange programming key to activate and deactivate the black ignition key.

#### **Possible states**

$\bigotimes$	Ignition <b>OFF</b> – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start. The ignition key can be removed.
$\bigcirc$	Ignition $\mathbf{ON}$ – In this position, the ignition circuit is closed and the engine can be started.
Ţ	Steering locked – In this position, the ignition circuit is interrupted and the steering locked. The ignition key can be removed.

#### Immobilizer



The electronic immobilizer secures the vehicle against unauthorized use. The immobilizer is activated automatically and the engine electronics are locked when the ignition key is withdrawn.

The red warning lamp flashes at 15 second intervals after one minute. The red warning lamp can also indicate errors by flashing.

#### Info

The ignition key contains electronic components. Never attach multiple ignition keys to a single key ring; this may cause mutual interference and lead to problems.

A lost black ignition key must be deactivated to prevent unauthorized persons from operating the vehicle.

The second black ignition key is activated when the vehicle is shipped.

Two additional spare ignition keys (key number on the **KEYCODECARD**) can be ordered from an authorized KTM workshop, but they must be activated before use.

### **Emergency OFF switch**



The emergency OFF switch  $\bullet$  is fitted on the right side of the handlebar.

#### **Possible states**

$\bigcirc$	Emergency OFF switch on – This position is necessary for operation as it closes the ignition circuit.
$\bigotimes$	Emergency OFF switch off – In this position, the ignition circuit is inter- rupted, a running engine stops, and the engine cannot be started.

### **Electric starter button**



The electric starter button  $\bullet$  is fitted on the right side of the handlebar.

#### **Possible states**

- Electric starter button (3) in basic position
- Electric starter button (3) pressed The electric starter is actuated in this position.


### **Combination instrument**



The combination instrument is installed in front of the handlebar.

- The combination instrument is divided into 4 function areas.
- Function buttons
- 2 Tachometer
- **③** Indicator lights
- Oisplay

#### **Combination instrument - function buttons**




You can change the display mode with the **MODE** button ①. Possible display modes are the distance traveled (**ODO**), trip master 1 (**TRIP 1**), trip master 2 (**TRIP 2**) and the ambient temperature.

Press the **SET** button O to reset the trip master 1 function (**TRIP 1**) and trip master 2 function (**TRIP 2**) to **0.0**.

Button <sup>(3)</sup> has no function.

### **Combination instrument - tachometer**



The tachometer **1** shows the engine speed in revolutions per minute. The red marking **2** shows the excess speed range of the engine.

# **Combination instrument - indicator lamps**




The indicator lamps offer additional information about the operating state of the motorcycle.


#### Possible states

	The turn signal indicator lamp flashes green simultaneously with the turn signal – The turn signal is switched on.
N	The idle speed indicator lamp lights up green – The transmission is shifted to idle.
	The high beam indicator lamp lights up blue – The high beam is switched on.
	The temperature warning lamp lights up red – The coolant temperature has reached a critical value.
	The fuel level warning lamp lights up orange – The fuel level has reached the reserve mark. The display switches to <b>TRIP F</b> .
<b>4127</b>	The oil pressure warning lamp lights up red – The oil pressure is too low.
FI	Warning lamp <b>FI (MIL</b> ) lights up/flashes orange – The OBD (on-board diagnosis) has detected an emission- or safety-critical error.
	The immobilizer indicator lamp lights up or flashes red – Status or error message for immobilizer/alarm system.
	The battery warning lamp lights up red – The voltage in the vehicle system is too low.

### **Combination instrument - display**



#### **Combination instrument - speedometer**




### Setting kilometers or miles

# • Info

If you change the unit, the value **ODO** is retained and converted accordingly. Making the setting according to the country.

Condition


The motorcycle is stationary.



#### – Switch on the ignition by turning the ignition key to the $\textbf{ON} \ \bigcirc$ position.

- Press the MODE button repeatedly until the ODO mode is active.
- Keep the MODE button pressed until the display mode changes from km/h to mph or from mph to km/h.

# **Combination instrument - time**




The time is shown in area  $\bullet$  of the display.



After reconnecting the battery or changing the fuse, the time must be reset.


# Setting the clock

#### **Condition** The motorcycle is stationary.



- Switch on the ignition by turning the ignition key to the  $\mathbf{ON}$   $\bigcirc$  position.
- Press the MODE button repeatedly until the ODO mode is active.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
  - ✓ The time display begins to flash.
- Press the **MODE** button to set the hour.
- Press the SET button to set the minute.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
  - ✓ The time is set.

### **Combination instrument - ODO display**



In the **ODO** display mode, the total distance traveled is shown in kilometers or miles.




This value is retained, even if the battery is disconnected and/or the fuse blows.

### **Combination instrument - setting/resetting TRIP 1**

### Info

The **TRIP 1** trip counter is always running and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.




- Switch on the ignition by turning the ignition key to the  $\textbf{ON} \bigcirc$  position.
- Press the **MODE** button repeatedly until the **TRIP 1** mode is active.
- Keep the **SET** button pressed.
  - The TRIP 1 display is set to 0.0.

# Combination instrument - setting/resetting TRIP 2

### lnfo


The **TRIP 2** trip counter is always running and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



- Switch on the ignition by turning the ignition key to the  $\textbf{ON} \bigcirc$  position.
- Press the MODE button repeatedly until the TRIP 2 mode is active.
- Keep the **SET** button pressed.
  - The TRIP 2 display is set to 0.0.

#### **Combination instrument - TRIP F display**




If the fuel level drops to the reserve mark, the display automatically changes to **TRIP F** and starts to count from **0.0**, regardless of the previous display mode.




The low fuel warning lamp lights up in parallel to the **TRIP F** display.

### **Combination instrument - ambient temperature display**



The ambient temperature **①** is displayed in °C or °F.

# Setting the temperature units




#### Condition

The motorcycle is stationary.

- Switch on the ignition by turning the ignition key to the  $\textbf{ON} \bigcirc$  position.
- Press the **MODE** button repeatedly until the ambient temperature is active.
- Keep the MODE button pressed until the display mode changes from °C to °F or from °F to °C.

### **Combination instrument - warning of slippery roads**




The ice symbol lights up to indicate an increased danger of slippery roads. The ice symbol appears in the display when the ambient temperature drops below the specified value.

Temperature	3 °C (37 °F)

The ice symbol  $\circledast$  goes out in the display when the ambient temperature rises above the specified value again.

Temperature	4 °C (39 °F)
-------------	--------------

# **Combination instrument - coolant temperature indicator**



The temperature display consists of 12 bars. The more bars that light up, the hotter the coolant. When the upper bar lights up, all bars in the display begin to flash and the temperature warning lamp lights up.

#### **Possible states**

- Engine cold Up to five bars light up.
- The engine is warm Six to eleven bars light up.
- Engine hot All twelve bars flash.

# Opening the filler cap



#### **Danger Fire hazard** Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



# Warning

**Danger of poisoning** Fuel is poisonous and a health hazard.


Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.



### Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Lift the cover of the filler cap **1** and insert the ignition key.

#### Note Danger of damage Ignition key breakage.

- To take pressure off of the ignition key, push down on the filler cap. Damaged ignition keys must be replaced.
- Turn the ignition key 90° counterclockwise and remove the filler cap.



Info


The filler cap has a tank air vent system.

# **Closing the filler cap**




- Put the filler cap back on and turn the ignition key  $90^{\circ}$  clockwise.
- Remove the ignition key and fold down the cover.

# Handrails



The handrails **①** are used for moving the motorcycle around. If you carry a passenger, the passenger can hold onto the handrails during the trip.

# Seat lock



Seat lock **①** is located at the rear under the tail light. It can be locked with the ignition key.

### **Tool set**



The tool set **1** is located in the storage compartment under the seat.

### **Helmet lock**



# Warning

**Danger of accidents** Impairment of ride behavior and vehicle operation if a helmet or helmet lock is attached to the vehicle.

Do not use the helmet lock for holding a helmet or other objects during the journey. Always remove the helmet lock before starting out.

The steel cable  ${\bf 0}$  in the tool set can be used to lock a helmet to the vehicle to prevent it from being stolen.

### **Passenger footrests**



The passenger footrests can be folded up and down.


#### **Possible states**

- Passenger footrests folded up For operation without a passenger.
- Passenger footrests folded down For operation with a passenger.

# Shift lever




Shift lever **1** is mounted on the left side of the engine.




The gear positions can be seen in the photograph. The neutral or idle position  ${\bf 0}$  is between the first and second gear.

# Foot brake lever



Foot brake lever **1** is located in front of the right footrest. The rear brake is activated using the foot brake lever.

# Side stand



The side stand  $\bullet$  is located on the left side of the vehicle. The side stand is used to park the motorcycle.

### Info

i

The side stand must be folded up during motorcycle use. Side stand is coupled with the safety start system; see the riding instructions.

#### **Possible states**

- Side stand folded out The vehicle can be leaned on the side stand. The safety start system is active.
- Side stand folded in This position is mandatory for all trips. The safety start system is inactive.

# Information on first use

Danger of accidents Danger arising from the rider's judgement being impaired.

 Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.



### Warning

Danger

Risk of injury Missing or poor protective clothing present an increased safety risk.

Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear
protective clothing, which must be undamaged and meet legal requirements.



#### Warning

Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



#### Warning

Danger of accidents Uncontrollable handling characteristic due to non-approved and/or non-recommended tires/wheels.

- Only tires/wheels approved by KTM and with the corresponding speed index should be used.



### Warning

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth rolling surface and therefore cannot provide full road grip. The entire rolling surface must be roughened in the first 200 kilometers (124.3 miles) by moderate riding at alternating angles. The full grip levels are not achieved until the tires have been run in.

#### Info

When using your vehicle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized KTM workshop.
  - ✓ You receive a delivery certificate and the service record at vehicle handover.
- Before your first trip, read the entire operating instructions carefully.
- Get to know the controls.

- Get used to handling the vehicle on empty suitable terrain before making a longer trip. Try also to ride as slowly as possible to get a better feeling for the motorcycle.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
- Run the engine in. (\* p. 53)

# Running in the engine

- Do not exceed the specified engine speed and load during the running-in period.

#### Guideline

Maximum engine speed	
During the first: 1,000 km (621.4 mi)	6,500 rpm
After the first: 1,000 km (621.4 mi)	9,500 rpm

Avoid full-throttle operation!

# Loading the vehicle



#### Warning

Danger of accidents Unstable handling characteristics.

 Do not exceed the maximum permitted weight and axle loads. The overall weight consists of: motorcycle operational and with a full tank, driver and passenger with protective clothing and helmet, baggage.



#### Warning

Danger of accidents Unstable handling characteristics due to incorrect mounting of suitcase and/or tank rucksack.

- Mount and secure suitcase and tank rucksack according to the manufacturer's instructions.



#### Warning

Danger of accidents Unstable handling characteristics at high speed.

Adapt your speed according to your payload. If the motorcycle is loaded with luggage, ride more slowly.
 Maximum speed with luggage 130 km/h (80.8 mph)



#### Warning

Danger of accidents Destruction of luggage carrier system.

- If the motorcycle is fitted with luggage cases, note the manufacturer's specifications concerning the maximum payload.



### Warning

**Danger of accidents** Poor visibility for other road users due to slipped baggage.

 If the tail light is covered, you are less visible to traffic behind you, especially in the dark. Check that your baggage is fixed properly at regular intervals.



#### Warning

Danger of accidents Changed handling characteristics and longer stopping distance with excessive payload.

- Adapt your speed according to your payload.



#### Warning

Danger of accidents Unstable handling characteristics due to slipped baggage.

- Check the way your baggage is fixed regularly.



#### Warning

Danger of burns A hot exhaust system can burn baggage.

- Fasten your baggage in such a way that it cannot be burned or singed by the hot exhaust system.

- If you are carrying baggage, make sure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.
- Do not exceed the maximum permissible total weight and the axle loads.

Guideline

Maximum permissible total weight	400 kg (882 lb.)
Maximum permissible front axle load	160 kg (353 lb.)
Maximum permissible rear axle load	250 kg (551 lb.)

#### Checks and maintenance measures when preparing for use

### Info

Before every trip, check the condition of the vehicle and ensure that it is roadworthy. The vehicle must be in perfect technical condition when it is being operated.

- Check the front brake fluid level. (\* p. 95)
- Check the rear brake fluid level. (\* p. 100)
- Check the front brake linings. (\* p. 97)
- Check the rear brake linings. (\* p. 102)
- Check that the brake system is functioning properly.
- Check the coolant level in the compensating tank. (\* p. 145)

- Check the tire condition. (\* p. 110)
- Check that all controls are correctly adjusted and free to move.
- Check that the electrical equipment is functioning properly.
- Check that baggage is correctly secured.
- Sit on the motorcycle and check the rear mirror setting.
- Check the fuel level.

# Starting

#### Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

 When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.



### Caution

**Danger of accidents** If the vehicle is operated with a discharged battery or without a battery, electronic components and safety equipment may be damaged.

- Never operate the vehicle with a discharged battery or without a battery.

#### Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



- Press the emergency OFF switch into the position  $\bigcirc$ .
- Switch on the ignition by turning the ignition key to the  ${\rm ON}$   $\bigcirc$  position.
  - ✓ After you switch on the ignition, you can hear the fuel pump working for about two seconds. The function test of the combination instrument is run at the same time.
- Shift the transmission to neutral.
  - ✓ The green idling speed indicator lamp **N** lights up.
- Press the electric starter button (3).

### Info

Do not press the electric starter button until the function test of the combination instrument is finished.

When starting, **DO NOT** open the throttle. If you open the throttle during the starting procedure, fuel is not injected by the engine management system and the engine cannot start.

Press the starter for a maximum of 5 seconds. Wait for a least 5 seconds before trying again.

This motorcycle is equipped with a safety start system. You can only start the engine if the transmission is in neutral or if the clutch is pulled when a gear is engaged. If the side stand is folded out and you shift into gear and release the clutch, the engine stops.

 Take the weight off the side stand and swing it upwards with your foot as far as it will go.

### Starting off

- Pull the clutch lever, engage 1st gear, release the clutch lever slowly and simultaneously open the throttle carefully.

# Shifting, riding



#### Warning

Danger of accidents Abrupt load alterations can cause the vehicle to get out of control.

- Avoid abrupt load alterations and sudden braking actions, and adapt your speed to the road conditions.



#### Warning

Danger of accidents If you change down at high engine speed, the rear wheel can lock up.

- Do not change into a low gear at high engine speed. The engine races and the rear wheel can lock up.



#### Warning

Danger of accidents Malfunctions caused by incorrect ignition key position.

- Do not change the ignition key position during a journey.



#### Warning

Danger of accidents Distraction from traffic activity by adjustments to the vehicle.

- Make all adjustments when the vehicle is at a standstill.



#### Warning

Risk of injury The passenger must be able to sit securely on the passenger seat.

The passenger must hold on to the rider or supporting strap firmly and place his/her feet on the passenger footrests. Observe
the regulations concerning the minimum age for passengers in your country.



#### Warning

Danger of accidents Danger of accidents caused by dangerous driving.

- Comply with traffic regulations and ride defensively and foresightedly to detect sources of danger early on.



#### Warning

Danger of accidents Reduced road grip with cold tires.

 On every journey, take the first miles carefully at moderate speed until the tires reach operating temperature and optimal road grip is ensured.



#### Warning

**Danger of accidents** Reduced road grip with new tires.

- New tires have a smooth rolling surface and therefore cannot provide full road grip. The entire rolling surface must be roughened in the first 200 kilometers (124.3 miles) by moderate riding at alternating angles. The full grip levels are not achieved until the tires have been run in.



#### Warning

Danger of accidents Unstable handling characteristics.

 Do not exceed the maximum permitted weight and axle loads. The overall weight consists of: motorcycle operational and with a full tank, driver and passenger with protective clothing and helmet, baggage.



### Warning

Danger of accidents Unstable handling characteristics due to slipped baggage.

- Check the way your baggage is fixed regularly.



#### Warning

Danger of accidents Lack of roadworthiness.

- After a fall, check the vehicle as usual before preparing for use.

#### Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.


#### Note

Engine damage Engine overheating.

If the coolant temperature warning lamp lights up, stop the vehicle and switch off the engine. Let the engine cool down, and then check the coolant level in the radiator and top up if necessary. If you continue your journey with the coolant temperature warning lamp on, this may cause engine failure.

### Info

If you hear unusual noises while riding, stop immediately, switch off the engine and contact an authorized KTM workshop.



- When conditions allow (incline, road situation, etc.), you can shift into a higher gear.
- Release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch and open the throttle.

### Info

- You can see the positions of the six forward gears in the figure. The neutral or idle position is between the first and second gears. First gear is used for starting off or for steep inclines.
- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is <sup>3</sup>/<sub>4</sub> open. This will barely reduce the speed but fuel consumption will be considerably lower.
- Accelerate only up to a speed suitable for the road surface and weather conditions.
   When traveling in bends, do not shift, and accelerate very carefully.
- To shift down, brake if necessary and close the throttle at the same time.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly and open the throttle or shift again.
- If the engine stalls (e.g. at a crossroads), pull the clutch lever only and press the starter button. You do not have to shift into neutral.

- Switch off the engine if you expect to be standing for a long time.
- If the FI warning lamp (MIL) lights up during a trip, stop immediately. When you shift to neutral, the FI warning lamp (MIL) starts to flash.

#### Info

From the flashing rhythm, you can derive a two-digit number, the so-called flashing code. The flashing code tells you which component has a fault.

- If the ice symbol \* appears in the combination instrument, the roads may be icy. Adapt your speed to the changed road conditions.

# **Braking**



# Warning

Danger of accidents If you brake too hard, the wheels can lock.

- Adapt your braking to the traffic situation and the road conditions.



#### Warning

Danger of accidents Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.



### Warning

**Danger of accidents** Reduced braking efficiency caused by spongy pressure point of front or rear brake.

- Check the brake system and do not continue riding. (Your authorized KTM workshop will be glad to help.)



### Warning

Danger of accidents Failure of brake system.

If the foot brake lever is not released, the brake linings drag continuously. The rear brake may fail due to overheating. Take your
foot off the foot brake lever when you are not braking.



#### Warning

**Danger of accidents** Longer stopping distance due to higher overall weight.

- Take the longer stopping distance into account when carrying a passenger and baggage.



### Warning

Danger of accidents Delayed brake action on salted roads.

- There may be salt deposits on the brake discs. In order to restore the normal braking efficiency, you will need to remove the deposits from the discs by carefully applying the brakes.
- When braking, first throttle back and then apply the front and rear brakes at the same time.
- On wet or slippery surfaces, mainly use the rear brake.
- Braking should always be completed before you enter a bend. Shift down to a lower gear that is appropriate to your speed.
- On long downhill stretches, use the braking effect of the engine. Do this by changing down two gears, but do not race the engine. You
  will require less braking force and the brakes will not overheat.

# Stopping, parking



### Warning

Risk of misappropriation Usage by unauthorized persons.

- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons. If you leave the vehicle, lock the steering and remove the ignition key.



#### Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber and brakes. Allow these components to cool down before starting work on them.

#### Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

#### Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being
run. Always let the vehicle cool first.

#### Note

Material damage Damage and destruction of components by excessive load.

- The side stand is designed for the weight of the motorcycle only. Do not sit on the motorcycle when it is supported by the side stand only. The side stand and/or the frame could be damaged and the motorcycle could fall over.
- Apply the brakes.
- Shift the transmission to neutral.
- Switch off the ignition by turning the ignition key to the  ${f OFF}\otimes{f position}.$

# • Info

If you switch off the engine with the emergency OFF switch but the ignition remains switched on at the ignition lock, power continues to flow to most power consumers and the battery is soon discharged. Therefore, always switch off the engine with the ignition key; the emergency OFF switch is provided for emergency situations only.

- Park the motorcycle on a firm surface.
- Swing the side stand to the front with your foot as far as it will go, and lean the vehicle onto it.
- Lock the steering by turning the handlebar fully to the left, pressing down the ignition key to the OFF position ⊗ and turning it to the position ⊕. To make the steering lock engage more easily, move the handlebar back and forth slightly. Remove the ignition key.

# Refueling

#### Danger



Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



# Warning

Danger of poisoning Fuel is poisonous and a health hazard.

Avoid contact of the fuel with skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel.

### Note

Material damage Premature clogging of the fuel filter.

- In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system. (Your authorized KTM workshop will be glad to help.)
- Only refuel with clean fuel that meets the specified standards.




# Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.

### Info

This motorcycle is equipped with a regulated catalytic converter. Leaded fuel will destroy the catalytic converter. You should therefore use unleaded fuel only.



- Switch off the engine.
- Open the filler cap. (\* p. 45)
- Fill the fuel tank with fuel up to measurement ().

Guideline

Measurement of (		35 mm (1.38 in)		
Total fuel tank capacity, approx.	15 I (4 US gal)	Super unleaded (ROZ 95 / RON 95 / PON 91) (  p. 197)		

- Close the filler cap. (\* p. 46)

#### Low octane fuel

### Note

Engine damage Low-quality fuel damages the engine.

- Operate the vehicle with fuel with an octane rating below 95 (ROZ 95 / RON 95 / PON 91) for no more than one tank full.
- The ignition curve must be adjusted to low octane fuel.
- Press the SET button Ø for two seconds.
  - ✓ The fuel level warning lamp switches off. TRIP F is set to 0.0 and appears in the previous display mode.

### Info

If you do not press the **SET** button **2**, the reset takes place automatically after about three minutes.



# SERVICE SCHEDULE

# Service schedule

	K10N	K75A	K150A	K300A
Check that the electrical equipment is functioning properly.	•	•	•	•
Read out the trouble code memory using the KTM diagnostics tool. 🔌	•	•	•	•
Check the measured service values with the KTM diagnostics tool. 🔌		•	•	•
Change the engine oil and filter, clean the oil screens. 🔌 (🕶 p. 156)	•	•	•	•
Check the oil jet for the clutch lubrication. 🔦	•		•	•
Check the front brake linings. (* p. 97)	•	•	•	•
Check the front brake discs. (* p. 94)	•	•	•	•
Check the rear brake linings. (* p. 102)	•	•	•	•
Check the rear brake disc. (	•	•	•	•
Check that brake lines are undamaged and free of leaks.	•	•	•	•
Check the rear brake fluid level. (* p. 100)	•	•	•	•
Check the free travel of the foot brake lever. (* p. 98)	•	•	•	•
Check the shock absorber and fork for leaks. Perform a fork and shock absorber service if needed and depending on vehicle use.	•	•	•	•
Check the swingarm bearings. 🔧		•	•	•
Check the wheel bearing for play. 🔌		•	•	•
Check the tire condition. (* p. 110)	•	•	•	•
Check the tire air pressure. (* p. 112)	•	•	•	•
Check the chain, rear sprocket and engine sprocket. (* p. 90)		•	•	•
Check the chain tension. (* p. 87)	•	•	•	•
Lubricate all moving parts (e.g. side stand, hand lever, chain,) and check for smooth operation. $\checkmark$	•	•	•	•

# SERVICE SCHEDULE

	K10N	K75A	K150A	K300A
Clean the dust boots of the fork legs.		•	•	•
Check the front brake fluid level. (* p. 95)	•	•	•	•
Bleed the fork legs. ( P. 81)		•	•	•
Check the steering head bearing play.	•	•	•	•
Change the spark plugs. 🔧			•	•
Check the valve clearance. 🔌			•	•
Check all hoses (e.g. fuel, cooling, bleeding, drainage,) and sleeves for cracking, leaks, and incorrect routing.			•	•
Check the antifreeze and coolant level. ( p. 143)	•	•	•	•
Check the wiring harness of the throttle valve body for damage and correct routing. $lacksquare$	•		•	•
Check the cables for damage and kink-free routing. 🔧			•	•
Check the control cables for damage, kink-free routing and adjustment.	•	•	•	•
Change the air filter. Clean the air filter box. 🔧			•	•
Check the fuel pressure. 🔧		•	•	•
Check the value of the manifold absolute pressure sensor (PM value) with the KTM diagnostics tool. $\checkmark$		•	•	•
Check the CO adjustment with the KTM diagnostics tool. 🔺		•	•	•
Check/rectify the fluid level of the hydraulic clutch. (* p. 93)		•	•	•
Check the fasteners for tightness. 🔌	•	•	•	•
Change the coolant. 🔧				•
Change the front brake fluid. 🔧			•	•
Change the rear brake fluid. 🔌			•	•
Check the clutch. 🔌			•	•

# SERVICE SCHEDULE

	K10N	K75A	K150A	K300A
Check the headlight setting. (     p. 137)	•	•	•	•
Check the radiator fan operation. 🔧	•	•	•	•
Final inspection: Check the vehicle of roadworthiness and take a test ride.	•	•	•	•
Read out the fault memory after a test ride using the KTM diagnostics tool. $lacksquare$	•	•	•	•
Make the service entries in the KTM DEALER.NET and service record.	•	•	•	•

**K10N:** Once after 1,000 km (621.4 mi) **K75A:** Every 7,500 km (4,660 mi) or annually **K150A:** Every 15,000 km (9,321 mi) or every 2 years **K300A:** Every 30,000 km (18,641 mi) or every 4 years

# TUNING THE CHASSIS

#### Fork/shock absorber



The fork and the shock absorber offer many options of adapting the suspension to your riding style and the payload.

#### Info


To help you adapt the vehicle, we have summarized our findings in Table ①. You can find the table on the air filter box after you remove the seat. In all settings except for the spring preload of the shock absorber, the value is adjusted by first turning the screw all the way in and then setting the value. Do not use excessive force to turn the adjusting screws against the stop, and take the last perceptible click as the end position.

These adjustments should be understood as a guideline and should always be the basis of your own personal suspension adaptation. Do not change the adjustments at random or by more than  $\pm$  40%, since otherwise the riding characteristics could deteriorate, particularly at high speeds.

# Adjusting the compression damping of the fork

#### Info

The hydraulic compression damping determines the fork suspension behavior. An optimally adjusted compression damping ensures that the fork does not compress too far and fast when you brake hard or when the load shifts very fast. It gives the rider good feedback about the road conditions.



− Turn adjusting screws ● clockwise all the way.

#### Info

- The adjusting screws are located at the bottom end of the fork legs. Make the same adjustment on both fork legs.
- Turn back counterclockwise by the number of clicks corresponding to the fork type. Guideline

Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

#### Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.


### Adjusting the rebound damping of the fork

### Info

The hydraulic rebound damping determines the fork rebound behavior.

An optimally adjusted rebound damping brakes the springing energy and enables a fast, vibration-free resetting of the fork to the zero position.

71



- Turn adjusting screws ● clockwise until they stop.

#### Info

- The adjusting screws are located at the top end of the fork legs. Make the same adjustment on both fork legs.
- Turn back counterclockwise by the number of clicks corresponding to the fork type. Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

#### Info


Turn clockwise to increase suspension damping; turn counterclockwise to reduce damping.

# Adjusting the spring preload of the fork

### Info

The spring preload defines the initial situation of the spring process of the fork.

The spring preload setting is optimal when it is set for the weight of the rider and that of any baggage and a passenger, and thus ensures a compromise between maneuverability and stability.



- Turn adjusting screws ● clockwise until they stop.

#### Info

- The adjusting screws are located at the top end of the fork legs. Make the same adjustment on both fork legs.
- Turn back counterclockwise by the number of turns corresponding to the fork type. Guideline

Spring preload - Preload Adjuster	
Comfort	5 turns
Standard	5 turns
Sport	3 turns
Full payload	3 turns

# • Info

Turn clockwise to increase preload, turn counterclockwise to reduce spring preload.

Changing the spring preload has no influence on the rebound damping although the adjusting screws turn during the adjustment work. However, you should also adjust the rebound damping when you alter the spring preload.

#### Compression damping of the shock absorber



The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed.

High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.

The high-speed setting, for example, has an effect on the landing after a jump: the rear wheel suspension compresses more quickly.

The low-speed setting, for example, has an effect when riding over long ground swells: the rear wheel suspension compresses more slowly.

These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

### Adjusting the low-speed compression damping of the shock absorber


Caution

**Danger of accidents** Disassembly of pressurized parts can lead to injury.

 The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)

### Info

The low-speed setting can be seen during the slow to normal compression of the shock absorber.



- Turn adjusting screw **1** clockwise with a screwdriver up to the last perceptible click.

lnfo

Do not loosen nut **2**!

- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed		
Comfort	25 clicks	
Standard	20 clicks	
Sport	15 clicks	
Full payload	15 clicks	

#### Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

### Adjusting the high-speed compression damping of the shock absorber


Danger of accidents Disassembly of pressurized parts can lead to injury.

 The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)

### Info

Caution

The high-speed setting can be seen during the fast compression of the shock absorber.



- Turn adjusting screw **1** clockwise all the way using a socket wrench.

lnfo

Do not loosen nut 2

- Turn back counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn

#### Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.


### Adjusting the rebound damping of the shock absorber



# Caution

Danger of accidents Disassembly of pressurized parts can lead to injury.

 The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized KTM workshop will be glad to help.)



- Turn adjusting screw **1** clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Rebound damping		
Comfort	20 clicks	
Standard	15 clicks	
Sport	10 clicks	
Full payload	10 clicks	

#### Info

Turn clockwise to increase suspension damping; turn counterclockwise to reduce damping.

### Adjusting the spring preload of the shock absorber 🔧



#### Warning

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.


- Following modifications, ride slowly at first to get the feel of the new ride behavior.

#### Info

The spring preload defines the initial situation of the spring process on the shock absorber.

The spring preload setting is optimal when it is set for the weight of the rider and that of any baggage and a passenger, and thus ensures a compromise between maneuverability and stability.

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.



- Take the weight off the rear wheel and swingarm.

# • Info

The spring preload can be adjusted correctly only if the rear wheel and the swingarm are fully relieved of weight.

- Loosen locking ring ①.
- Turn adjusting ring 2 until the spring is no longer under tension.

Hook wrench (T106S)

- Measure the overall spring length without a load.
- Tension the spring by turning adjusting ring 2 to the prescribed value.
   Guideline

Spring preload	
Comfort	11 mm (0.43 in)
Standard	11 mm (0.43 in)
Sport	11 mm (0.43 in)
Full payload	13 mm (0.51 in)


Tighten locking ring ①.

### Raising the motorcycle with the front wheel stand

#### Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Raise the motorcycle with the rear wheel stand. (\* p. 80)
- Move the handlebar to the straight-ahead position. Align the front wheel stand with the fork legs using the adapters.

Front wheel stand (61029055300)

### Info

- Always raise the rear of the motorcycle first.
- Raise the front of the motorcycle.

### Taking the motorcycle off of the front wheel stand

#### Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Secure the motorcycle against falling over.
- Remove the front wheel stand.

### Raising the motorcycle with the rear wheel stand

#### Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Insert the adapter in the rear wheel stand.

Adapter (61029055120)

Rear wheel stand (61029055100)

 Stand the motorcycle upright, align the wheel stand with the link fork and the adapters, and lift the motorcycle.


### Taking the motorcycle off of the rear wheel stand

#### Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Secure the motorcycle against falling over.
- Remove the rear wheel stand and lean the vehicle on the side stand.

### **Bleeding the fork legs**




- Lean the motorcycle on the side stand.
- Remove bleeder screws ① briefly.
  - $\checkmark$  Any excess pressure escapes from the interior of the fork.
- Mount and tighten the bleeder screws.




Carry out this operation on both fork legs.

### Removing the seat



- Insert the ignition key in the seat lock **1** and turn it clockwise.
- Raise the rear of the seat, push it towards the rear, and remove it upwards.
- Remove the ignition key from the seat lock.

### Mounting the seat



- Position front recesses **1** of the seat on the oval head screws of the fuel tank, lower the rear and simultaneously push it forward. Both lugs **2** must hook into the frame and locking bolt **3** must be inserted into the lock housing.
  - ✓ The seat engages with an audible click.
- Finally, check that the seat is correctly mounted.

### Mounting the helmet lock on the vehicle



### Warning

**Danger of accidents** Impairment of ride behavior and vehicle operation if a helmet or helmet lock is attached to the vehicle.

 Do not use the helmet lock for holding a helmet or other objects during the journey. Always remove the helmet lock before starting out.




- Remove the seat. (\* p. 81)
- Position the steel cable from the tool set with one loop on the lug  $oldsymbol{0}$ .

Steel cable (60012015000)

- Guide the steel cable through the helmet opening.
- Then position the free loop of the steel cable on the lug.
- Position the helmet carefully on the side of the vehicle.
- Mount the seat. (🕶 p. 82)

# Reinstalling the fuel tank






- Remove the seat. (\* p. 81)
- Remove screws **1** and the spoiler on both sides.


Remove screw ② on both sides.



### The fuel hoses do not need to be disconnected.



# Positioning the fuel tank



- Remove screw <sup>3</sup>.
- Carefully push the fuel tank back.

- Carefully push the fuel tank forward.
- Mount and tighten screw 

   with the collar bushing.
   Guideline

Remaining chassis screws	M6	10 Nm (7.4 lbf ft)
--------------------------	----	--------------------





 Install and tighten screw ② with the bearing sleeve and rubber sleeve on both sides. Check the fuel tank for tightness.


Guideline

Remaining chassis screws	M8	25 Nm (18.4 lbf ft)
--------------------------	----	------------------------

- Check the routing of the fuel lines.
- Position the spoilers on both sides. Mount and tighten screws **③**.
   Guideline

Screw, spoiler	M6	3.3 Nm (2.43 lbf ft)
----------------	----	-------------------------

### Checking the chain for dirt



- Check the chain for coarse dirt accumulation.
  - » If the chain is very dirty:
    - Clean the chain. (🕶 p. 86)

### **Cleaning the chain**



### Warning

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.



#### Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.




### Warning

**Environmental hazard** Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

### Info

The service life of the chain depends largely on its maintenance.



- Clean the chain regularly.
- Rinse off loose dirt with a soft jet of water.
- Remove old grease remains with chain cleaner.

Chain cleaner (🕶 p. 198)

• After drying, apply chain spray.

Chain lube for road use (\* p. 198)


# Checking the chain tension



### Warning

**Danger of accidents** Danger caused by incorrect chain tension.

If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.



- Lean the motorcycle on the side stand.
- Shift the transmission to neutral.
- In the area after the chain sliding guard, press the chain upward toward the link fork and measure chain tension ().

#### Info

The upper chain section **B** must be taut.

Chain wear is not always even, so you should repeat this measurement at different chain positions.

7 mm (0.28 in)

- » If the chain tension does not meet specifications:
  - Adjust the chain tension. (\* p. 88)


# Adjusting the chain tension



### Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.
  - Check the chain tension. (\* p. 87)



- Loosen nut **1**.
- Loosen nuts 🛛.

Chain tension	7 mm (0.28 in)
Turn adjusting screws ③ on the left and rig right chain adjuster ④ are in the same pos rear wheel is then correctly aligned.	5

### Info

The upper chain section must be taut.

Chain wear is not always even, so you should check the setting at different chain positions.

- Tighten nuts 2.
- Make sure that chain adjusters ④ are resting against adjusting screws ⑤.
- Tighten nut **1**.


Guideline

Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)	Thread greased
-------------------------	---------	------------------------	----------------

### Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary transmissions with the same chain length. Chain adjusters ④ can be turned through 180°.


### Checking the chain, rear sprocket and engine sprocket



- Check the rear sprocket and engine sprocket for wear.
  - » If the rear sprocket or engine sprocket is worn:
    - Replace the rear sprocket or engine sprocket.

### Info

The rear sprocket, engine sprocket and chain should always be changed together.



- Shift the transmission to neutral.

Guideline

Weight, chain wear measurement	15 kg (33 lb.)
--------------------------------	----------------

- Measure the distance <sup>()</sup> of 18 chain links in the lower chain section.

#### lnfo

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance 🖲 at the longes	st 272 mm (10.71 in)
chain section	


- » If distance **B** is greater than the specified measurement:
  - Replace the chain. 🔌

#### Info

When the chain is replaced, the rear sprocket and engine sprocket should also be changed.

New chains wear out faster on old, worn sprockets.

For safety reasons, the chain has no chain joint.



- Check the chain sliding guard for wear.
  - » If the chain sliding guard is worn:
    - Change the chain sliding guard. 🔌
- Check the chain sliding guard for tightness.
  - » If the chain sliding guard is loose:
    - Tighten the chain sliding guard.
       Guideline

Screw, chain sliding guard	M5	5 Nm (3.7 lbf ft)	-
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™

# Adjusting the basic position of the clutch lever

### lnfo


Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar.

Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.

Do not make any adjustments while riding!




Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ①.

# Checking/rectifying the fluid level of the hydraulic clutch

#### Info

The fluid level rises with increasing wear of the clutch lining disc. Do not use brake fluid.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover 2 with membrane 3.
- Check the fluid level.


Fluid level below top edge of container	4 mm (0.16 in)
---	----------------

- » If the coolant level does not meet specifications:
  - Correct the fluid level of the hydraulic clutch.

Hydraulic fluid (15) (🕶 p. 196)

- Position the cover with the membrane. Mount and tighten the screws.

### Adjusting the basic position of the hand brake lever



Pull the brake lever forwards.

Adjust the basic setting of the hand brake lever to your hand size by turning adjusting wheel ①.



Do not make any adjustments while riding!


### Checking the front brake discs



# Warning

Danger of accidents Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay. (Your authorized KTM workshop will be glad to help.)



Check the thickness of the brake disc in several places to see if it conforms to measurement ①.

Info

Wear reduces the thickness of the brake discs in area  $\bullet$  of the brake discs.

Brake discs - wear limit	
Front	4.5 mm (0.177 in)

» If the brake disc thickness is less than the specified value:

- Change the brake discs. 🔌
- Check the brake discs for damage, cracking and deformation.
  - » If the brake discs exhibit damage, cracking or deformation:
    - Change the brake discs. 🔌

### Checking the front brake fluid level



#### Warning

Danger of accidents Failure of the brake system.


- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized KTM workshop will be glad to help.)

# Wa

Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

 Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized KTM workshop will be glad to help.)



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the brake fluid reservoir **①**.
  - » If the brake fluid is below the MIN marking:
    - Add front brake fluid. 🔌 (🕶 p. 96)

## Adding front brake fluid 🔧



### Warning

Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized KTM workshop will be glad to help.)



# Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



### Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

 Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized KTM workshop will be glad to help.)



### Warning

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

### Info

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid is corrosive and will damage painted surfaces.

Use only clean brake fluid from a sealed container.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws.
- Remove cover **1** with membrane **2**.
- Add brake fluid to the MAX level.

Brake fluid DOT 4 / DOT 5.1 (\* p. 194)

- Position the cover with the membrane. Mount and tighten the screws.



Clean up overflowed or spilt brake fluid immediately with water.

### **Brake linings**

The brake linings fitted by KTM have been tested over long periods and guarantee optimal braking characteristics. The type names of the brake linings are entered in the homologation documents.

### Info

Brake linings available in accessories shops are often untested and unapproved for use on KTM vehicles. The structure and friction coefficient of the brake linings, and therefore the brake power, can vary considerably from the original KTM brake linings. If brake linings other than those supplied as originals are used, there is no guarantee that they correspond to the original homologation. The vehicle then no longer corresponds to the condition at delivery and the guarantee is no longer valid.

### Checking the front brake linings



# Warning


Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized KTM workshop will be glad to help.)

### Note

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are rendered unserviceable. Check the brake linings regularly.



Check all brake linings on both brake calipers to ensure they have minimum thickness (a).

Minimum thickness 🔕	≥ 1 mm (≥ 0.04 in)
---------------------	--------------------

- » If the minimum thickness is less than specified:
  - Change the front brake linings. 🔌
- Check all brake linings on both brake calipers for damage and cracking.
  - » If damage or wear is encountered:
    - Change the front brake linings. 🔌


### Checking the free travel of the foot brake lever



#### Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Move the foot brake lever back and forth between the end stop and the contact to the piston rod and check free travel **(a)**.

Guideline

Free	travel at foot brake lever	3 5 mm (0.12 0.2 in)	
i	<b>Info</b> The piston rod should not move.		

- » If the free travel does not meet specifications:
  - Adjust the free travel to the specified value.


### Checking the rear brake disc



#### Warning

**Danger of accidents** Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay. (Your authorized KTM workshop will be glad to help.)



Check the thickness of the brake disc in several places to see if it conforms to measurement .

Info

Wear reduces the thickness of the brake disc in area **1** of the brake disc.

Brake disc - wear limit	
Rear	4.5 mm (0.177 in)

- » If the brake disc thickness is less than the specified value:
  - Change the brake disc. 🔌

- Check the brake disc for damage, cracking and deformation.
  - » If damage, cracks or deformation are visible on the brake disc:
    - Change the brake discs. 🔌

#### Checking the rear brake fluid level



### Warning

**Danger of accidents** Failure of the brake system.


If the brake fluid level falls below the MIN mark, this indicates a leakage in the brake system or worn-out brake linings. Check
the brake system and do not continue riding. (Your authorized KTM workshop will be glad to help.)



#### Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

 Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized KTM workshop will be glad to help.)



- Stand the vehicle upright.
- Check the brake fluid level of the brake fluid reservoir.
  - » If the fluid level reaches the MIN mark ①:
    - Add rear brake fluid. 🔌 (🕶 p. 101)

### Adding rear brake fluid 🔧



#### Warning

Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized KTM workshop will be glad to help.)



# Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



### Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

 Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized KTM workshop will be glad to help.)



#### Warning

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.


### Info

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid is corrosive and will damage painted surfaces.

Use only clean brake fluid from a sealed container.





# Remove screws 1.

Remove cover  $\boldsymbol{2}$  with membrane  $\boldsymbol{3}$ .

Add brake fluid to level **(A**).

Brake fluid DOT 4 / DOT 5.1 (\* p. 194)

Position the cover with the membrane. Mount and tighten the screws.



#### Info

Clean up overflowed or spilt brake fluid immediately with water.

### Checking the rear brake linings



Warning


Danger of accidents Reduced braking efficiency caused by worn brake linings.

Change worn brake linings immediately. (Your authorized KTM workshop will be glad to help.)

### Note

**Danger of accidents** Reduced braking efficiency caused by damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are rendered unserviceable. Check the brake linings regularly.




- Check the brake linings for minimum thickness ().


Minimum thickness 🔕	≥ 1 mm (≥ 0.04 in)	
---------------------	--------------------	--

- » If the minimum thickness is less than specified:
  - Change the rear brake linings. 🔌
- Check the brake linings for damage and cracking.
  - » If damage or wear is encountered:
    - Change the rear brake linings. 🔌

# WHEELS, TIRES

### Removing the front wheel 🔧





- Raise the motorcycle with the rear wheel stand. (\* p. 80)
- Remove the screws **1** from both brake calipers.
- Press back the brake linings with a light lateral tilting of the brake calipers on the brake disc. Pull the brake calipers carefully back from the brake discs and hang them to one side.

# lnfo

Do not pull the hand brake lever when the brake calipers are removed.

- Loosen screws 2 and 3.
- Unscrew screw 2 about six turns and press your hand on the screw to push the wheel spindle out of the axle clamp. Remove screw 2.

# Warning

**Danger of accidents** Reduced braking efficiency caused by damaged brake discs.

- Always lay the wheel down in such a way that the brake discs are not damaged.
- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.


# WHEELS, TIRES

# Installing the front wheel 🔌



Warning **Danger of accidents** Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
  - » If the wheel bearing is broken or worn:
    - Replace the wheel bearing. 🛁
- Grease and mount the left and right spacers and the shaft seal rings.


Long-life grease (🕶 p. 199)

- Clean screw **1** and wheel spindle **2**.
- Lift the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw **1**.

Guideline

Bolt, front axle	M25x1.5	45 Nm (33,2 lbf ft)

# WHEELS, TIRES



- Position the brake calipers and check that the brake linings are seated correctly.
- Mount screws 3 on both brake calipers but do not tighten yet.
- Operate the hand brake lever repeatedly until the brake lining presses up against the brake disc and there is a pressure point. Fix the hand brake lever in its engaged position.
  - ✓ The brake calipers straighten.
- Tighten screws **3** on both brake calipers.


Guideline

Screw, front brake caliper	M10x1.25	45 Nm (33.2 lbf ft)	Loctite <sup>®</sup> 243™
----------------------------	----------	------------------------	---------------------------


- Remove the fixation of the hand brake lever.
- Take the motorcycle off of the front wheel stand. ( p. 79)
- Take the motorcycle off of the rear wheel stand. ( Tp. 80)
- Pull the front brake and compress the fork powerfully a few times.
  - ✓ The fork legs straighten.
- Fully tighten screws 4.

Guideline

Screw, fork stub	M8	15 Nm
		(11.1 lbf ft)



### Removing the rear wheel $\boldsymbol{\prec}$





- Raise the motorcycle with the rear wheel stand. (\* p. 80)
- Remove nut 1. Remove chain adjuster 2.
- Pull out wheel spindle ③ to the point where the chain adjuster is no longer in contact with the adjusting screw.

- Push the rear wheel forward as far as possible and take the chain off the rear sprocket.
- Withdraw the wheel spindle.
- Pull the rear wheel backward until the brake caliper support hangs free between the brake disc and the wheel rim.



#### Warning

- **Danger of accidents** Reduced braking efficiency caused by damaged brake discs.
- Always lay the wheel down in such a way that the brake discs are not damaged.
- Take the rear wheel carefully out of the swingarm without damaging the rim and/or brake disc.



Do not operate the foot brake when the rear wheel is removed.

### Installing the rear wheel 🔧



### Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



### Warning

Danger of accidents No braking effect when operating the rear brake.

- After installing the rear wheel, always operate the foot brake until the pressure point is reached.




- − Check the rear hub shock absorbers. ◀ (♥ p. 109)
- Check the wheel bearing for damage and wear.
  - » If the wheel bearing is broken or worn:
    - Replace the wheel bearing. 🔌
- Remove spacer ①. Clean and grease the mating surfaces of the spacers and the shaft seal rings.

Long-life grease (🕶 p. 199)

- Install the spacer.
- Clean and grease the thread of the wheel spindle and nut.

Long-life grease (\* p. 199)

- Clean the fixing locations on the brake caliper support and swingarm.



- Engage the counter bearing of the brake caliper support (a) and swingarm. Lay the chain on the rear sprocket and mount the wheel spindle.
- Mount chain adjuster 2 and nut 3.



Mount the left and right chain adjusters in the same position.

 Push the rear wheel forward so that the chain adjusters are in contact with the adjusting screws, and tighten the nut.

Guideline

In order for the rear wheel to be correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to the reference marks **(B**).

Nut, rear wheel spindleM25x1.590 NmThread greased(66.4 lbf ft)
--

- Operate the foot brake lever repeatedly until the brake linings lie on the brake disc and there is a pressure point.
- Check the chain tension. (\* p. 87)

### Checking rear hub shock absorbers 🔌

#### Info

The engine power is transmitted by the rear sprocket to the rear wheel through five shock absorbers. They eventually wear out during operation. If the shock absorbers are not changed in time, the rear sprocket carrier and the rear hub are damaged.

– Remove the rear wheel. 🔌 (🕶 p. 107)



- Remove the rear sprocket carrier.
- Check the rear hub for damage and wear.
  - » If the rear hub shock absorbers are damaged or worn:
    - Change the rear hub shock absorber. 🔌
- Position the rear sprocket carrier.

### Info

- A set of bolts and shock absorbers should have as little free travel as possible to increase the service life of the shock absorbers.
- Install the rear wheel. 🔌 (🕶 p. 108)

### Checking the tire condition



#### Warning

Danger of accidents Uncontrollable vehicle handling in the event of a flat tire.

- In the interest of safety, replace damaged or worn tires immediately. (Your authorized KTM workshop will be glad to help.)



#### Warning

**Danger of crashing** Poor vehicle handling due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



#### Warning

Danger of accidents Uncontrollable handling characteristic due to non-approved and/or non-recommended tires/wheels.

- Only tires/wheels approved by KTM and with the corresponding speed index should be used.




#### Warning

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth rolling surface and therefore cannot provide full road grip. The entire rolling surface must be roughened in the first 200 kilometers (124.3 miles) by moderate riding at alternating angles. The full grip levels are not achieved until the tires have been run in.

### Info

The type, condition and air pressure of the tires all have a major impact on the handling of the motorcycle. Worn tires have a negative effect on vehicle handling, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects and other damage.
  - » If the tires exhibit cuts, run-in objects or other damage:
    - Change the tires.
- Check the depth of the tread.

### Info

Note local national regulations concerning the minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	--------------------

- » If the tread depth is less than the minimum permissible depth:
  - Change the tires.
- Check the age of the tires.


#### Info

- The tire's date of manufacture is usually part of the tire markings and is indicated by the last four digits of the **DOT** marking. The first two digits refer to the week of manufacture and last two digits refer to the year of manufacture. KTM recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.
- » If a tire is more than five years old:
  - Change the tires.

### Checking the tire air pressure

#### Info

Low tire air pressure leads to abnormal wear and overheating of the tire. Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove the dust cap.
- Check the tire air pressure when the tires are cold.

Tire air pressure, solo		
Front	2.2 bar (32 psi)	
Rear	2.2 bar (32 psi)	
Tire air pressure with passenger/full payload		
Front	2.4 bar (35 psi)	
Rear	2.5 bar (36 psi)	

» If the tire pressure does not meet specifications:

- Correct the tire pressure.

### Info

i

The rubber seal in the dust cap prevents air from leaking out of the tire if the valve is faulty.

## Removing the battery 🔧



Warning

**Risk of injury** Battery acid and battery gases cause serious chemical burns.


- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open flames. Charge only in well-ventilated areas.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.

## Λ


Caution

**Danger of accidents** If the vehicle is operated with a discharged battery or without a battery, electronic components and safety equipment may be damaged.

- Never operate the vehicle with a discharged battery or without a battery.




- Switch off all power consumers and the engine.
- Disconnect negative (minus) cable **1** of the battery.



- Remove positive terminal cover 2. \_
- Disconnect the positive (plus) cable **3** of the battery. \_
- Detach rubber band **4**. \_
- Pull the battery up and out of the battery rack. \_

## Installing the battery 🔧




Position the battery in the battery rack.



The terminals of the battery must face in the direction of travel.

- Attach rubber band **①**. \_
- Reconnect the positive (plus) **2** cable of the battery. \_
- Position positive terminal cover **③**. \_



### Recharging the battery 🔧



### Warning

**Risk of injury** Battery acid and battery gases cause serious chemical burns.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open flames. Charge only in well-ventilated areas.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.



### Warning

**Environmental hazard** Battery parts and acid are harmful to the environment.

Do not discard batteries with the household trash. Dispose of a defective battery in an environmentally compatible manner.
 Give the battery to your KTM dealer or to a recycling center that accepts used batteries.

- Reconnect the negative (minus) cable 4 of the battery.
- Set the clock. (**\*** p. 40)



### Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

### • Info

Even when there is no load on the battery, it discharges steadily.

The charge state and the type of charge are very important for the service life of the battery.


Rapid recharging with a high charging current shortens the battery's service life.

If the charging current, charging voltage and charging time are exceeded, electrolyte escapes through the safety valves. This reduces the battery capacity.

If the battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.

If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfate, destroying the battery. The battery is maintenance-free, i.e., the acid level does not have to be checked.

- Switch off all power consumers and switch off the engine.
- Disconnect the negative (minus) cable of the battery to avoid damage to the motorcycle's electronics.



### Changing the main fuse



Warning

Fire hazard The electrical system can be overloaded if the wrong fuses are used.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (58429074000)

You can also use the battery charger to test the rest potential and start potential of the battery, and to test the alternator. With this device, you cannot overcharge the battery.

### Info

Never remove lid **1**.

Charge the battery at no more than 10% of the capacity specified on battery housing  $\boldsymbol{2}$ .


- Switch off the charger after charging. Disconnect the battery.

Guideline

The charge current, charge voltage and charge time must not be exceeded.			
Charge the battery regularly when the 3 months motorcycle is not in use			

### Info

The main fuse protects all power consumers of the vehicle. The main fuse is under the seat.



- Switch off all power consumers and the engine.
- Remove protection covers ①.
- Remove the faulty main fuse 2.

#### • Info A de

A defective fuse can be identified by the burned-out fuse wire (a). A reserve fuse (c) is located in the starter relay.

- Install a new main fuse.

Fuse (58011109130) (🕶 p. 186)



### Tip

Place the spare fuse in the starter relay so that it is available if needed.

- Attach the protection covers ①.
- Mount the seat. (🕶 p. 82)

### Changing the fuses of individual power consumers


### Warning

Fire hazard The electrical system can be overloaded if the wrong fuses are used.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

### Info

The fuse box containing the fuses of individual power consumers is located under the seat.



- Switch off all power consumers and the engine.
- Open fuse box cover ①.
- Check the fuses.



A defective fuse can be identified by the burned-out fuse wire (a). Spare fuses (2) are also found in the storage compartment.

- Remove the faulty fuse.

Guideline

Fuse **IGNITION, FUEL PUMP** - 10 A - ignition, fuel pump, immobilizer, alarm system (optional)

Fuse **H/L BEAM, POSITION** - 15 A - high beam, low beam, parking light, license plate lamp

Fuse HORN, BRAKE LIGHT - 10 A - horn, brake light, hazard warning flasher

Fuse FAN - 10 A - radiator fan

Fuse POWER RELAY - 10 A - ignition (EFI control unit)

Fuse **ACC1, CLOCK** - 10 A - combination instrument, socket, supplementary devices (permanent positive), alarm system (optional)

Fuse ACC2 - 10 A - supplementary equipment (accessories connected to the ignition switch)

Fuse ABS, OPTIONAL - not used

Use spare fuses with the correct rating only.

Fuse (58011109110) (🕶 p. 186)

Fuse (58011109115) (\* p. 186)

### Tip

Insert the spare fuse so that it is available if needed.

- Close the fuse box cover.
- Mount the seat. (🕶 p. 82)


## Changing the headlight bulb

### Note

Damage to reflector Reduced luminance.

 Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.


Switch off all power consumers and the engine.





Remove screws 1.

\_

- Cover the fender with a cloth.
- Swing the headlight mask forward and pull it upward out of holding lugs 2.







- Disconnect connector **3**.
- Remove rubber cap **4**.

- Push off retaining clamp **6** on both sides, squeeze and fold down.
- Remove headlight bulb 6. \_
- Position the new headlight bulb in the headlight housing. \_


Low beam/high beam (H4/socket P43t) ( P. 186)



### Info

Insert the headlight bulb so that the bayonet lugs latch into the slots.

- Position the retaining clamp. \_
- Mount rubber cap **4**. \_
- Plug in connector **3**.



### Changing the parking light bulb

### Note

Damage to reflector Reduced luminance.


- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.
  - Switch off all power consumers and the engine.


Position holes **1** onto holding lugs **2**.

Position the headlight mask. Mount and tighten screws ①.
 Guideline

Remaining chassis screws	M6	10 Nm (7.4 lbf ft)
--------------------------	----	--------------------


- Check that the lighting is functioning properly.







- Cover the fender with a cloth.
- Swing the headlight mask forward and pull it upward out of holding lugs **2**.





- Pull the parking light <sup>(4)</sup> carefully out of the holder.
- Remove the bulb.
- Position a new light bulb in the holder.

Parking light (W5W/socket W2.1x9.5d) (🕶 p. 186)

- Carefully position the holder with the bulb into the holder in the headlight.

- Position holes 6 onto holding lugs 2.





- Position the headlight mask. Mount and tighten screws **①**.

Guideline

Remaining chassis screws	M6	10 Nm (7.4 lbf ft)
--------------------------	----	--------------------


- Check that the lighting is functioning properly.

### Changing the turn signal bulb

#### Note

Damage to reflector Reduced luminance.

 Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



- Remove the screw on the rear of the turn signal housing.
- Carefully remove diffuser ①.
- Press bulb ② carefully into the socket, turn it counterclockwise by about 30°, and pull it out of the socket.
- Press the new bulb carefully into the socket and turn it clockwise until it stops.

Turn signal (RY10W/socket BAU15s) (\* p. 186)

- Check the turn signal to make sure it is functioning properly.
- Position the diffuser.
- Insert the screw and first turn it counterclockwise until it engages in the thread. Tighten the screw slightly.


127

## Changing the brake light bulb


#### Note

Damage to reflector Reduced luminance.

 Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.





- Remove screws **①**.
- Remove the grab handles.



- Remove screws 2.
- Remove screws **③** on the left and right rear side part.
- Remove the rear side part.

- 4 0 0 101150-10
- Remove screws 4.
- Remove the top part.





- Turn bulb socket **G** counterclockwise all the way and take it out of the tail light.
- Push the bulb carefully into the socket, turn it counterclockwise and pull it out of the socket.
- Press the new bulb carefully into the socket and turn it clockwise until it stops.


Brake light (P21W/socket BA15s) (\* p. 187)

- Insert the bulb socket into the tail light and turn clockwise until it stops.
- Check that the brake light system is functioning properly.

- Position the rear top part.
- Mount and tighten screws 4.

Guideline

Remaining chassis screws	M6	10 Nm (7.4 lbf ft)
8		





- Position the rear side parts.
- Mount and tighten screws **2**.

Guideline

Remaining chassis screws	M5	5 Nm (3.7 lbf ft)
--------------------------	----	-------------------

– Mount and tighten screws  $\ensuremath{\mathfrak{S}}$  on the left and right rear side part.

Guideline

Screw, rear side part	EJOT	Initial screw con- nection 3.3 Nm (2.43 lbf ft) Subsequent screw
		connection 2 Nm (1.5 lbf ft)

- Position the grab handles.
- Mount and tighten screws **①**.

Guideline


Remaining chassis screws	M8	25 Nm (18.4 lbf ft)
--------------------------	----	------------------------

## Changing the tail light bulbs


### Note

Damage to reflector Reduced luminance.

 Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.





- Remove screws ①.
- Remove the grab handles.



- Remove screws 2.
- Remove screws **③** on the left and right rear side part.
- Remove the rear side part.

- 4 0 0 101150-10
- Remove screws 4.
- Remove the top part.





- Pull bulb holders **③** carefully out of the bracket.
- Remove the bulb.
- Position a new light bulb in the holder.


Tail light (W5W/socket W2.1x9.5d) (\* p. 187)


- Carefully position the holders with the bulbs into the holder in the tail light.
- Check that the tail light bulbs are functioning properly.

- Position the rear top part.
- Mount and tighten screws 4.

Guideline

Remaining chassis screws	M6	10 Nm (7.4 lbf ft)
--------------------------	----	--------------------





- Position the rear side parts.
- Mount and tighten screws **2**.

Guideline

Remaining chassis screws	M5	5 Nm (3.7 lbf ft)
--------------------------	----	-------------------

– Mount and tighten screws  $\ensuremath{\mathfrak{S}}$  on the left and right rear side part.

Guideline


Screw, rear side part	EJOT	Initial screw con- nection 3.3 Nm (2.43 lbf ft) Subsequent screw
		connection 2 Nm (1.5 lbf ft)


- Position the grab handles.
- Mount and tighten screws **①**.

Guideline

Remaining chassis screws	M8	25 Nm (18.4 lbf ft)
--------------------------	----	------------------------

### Changing the license plate lamp






- Remove screws 1.
- Remove the license plate lamp cover.

- Pull holder **2** carefully out of the bracket.
- Remove the bulb.
- Position a new light bulb in the holder.

License plate lamp (W5W/socket W2.1x9.5d) ( p. 187)


- Carefully position the holder with the bulb into the bracket.



### - Position the cover.

- Mount and tighten screws **1**.
- Check that the license plate lamp is functioning properly.

### Checking the headlight setting



- Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the level of the center of the headlight.
- Make another mark at a distance of **1** under the first mark.

Guideline

Distance <sup>(3)</sup> 5 cm (2 in)
-------------------------------------

Park the vehicle at a distance of 
vertically in front of the wall and switch on the low
beam headlight.

Guideline


|--|

- The rider, with luggage and passenger if applicable, now mounts the motorcycle.
- Check the headlight setting.

The light-dark boundary must lie exactly on the lower mark when the motorcycle is ready to operate with the rider mounted along with any luggage and a passenger if applicable.

- » If the boundary between light and dark does not meet specifications:

### Adjusting headlight range



- Turn screw **1** to adjust the headlight range.

#### Guideline

For a motorcycle with rider, and with luggage and a passenger if applicable, the light/dark boundary must be exactly on the lower mark (applied in: Checking headlight adjustment).

### Info

Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.

### Activating/deactivating the ignition key


### Info

dure.

The orange programming key must only be used for activating and deactivating!

If a black ignition key is lost or replaced, the black ignition keys must be activated/deactivated using the orange programming key. This will also prevent the vehicle from being operated without authorization with the lost black ignition key. You can activate or deactivate up to four black ignition keys. Only the black ignition keys trained during an activation procedure are valid. All black ignition keys not trained in the activation procedure are invalid, but can be retrained in a further activation proce-

138






### Loss of a black ignition key (second black ignition key available):

The following procedure deactivates all activated black ignition keys that are not included in the procedure.

– Press the emergency OFF switch into the position  $\bigcirc$ .

- Insert the orange programming key in the ignition lock.
- Switch on the ignition by turning the orange programming key to the **ON** position  $\bigcirc$ .
  - ✓ **FI** Warning lamp <sup>⊕</sup> (**MIL**) lights up, switches off, and then starts to flash.
  - ✓ Immobilizer indicator lamp <sup>⊕</sup> lights up.
- Switch off the ignition by turning the orange programming key to the OFF position ⊗.
- Pull out the programming key.
- Insert the black ignition key in the ignition lock.
- Switch on the ignition by turning the ignition key to the  $\textbf{ON} \bigcirc$  position.
  - ✓ **FI** Warning lamp <sup>⊕</sup> (**MIL**) lights up, switches off, and then starts to flash.
  - Immobilizer indicator lamp 

     lights up, switches off briefly, and lights up again.
- Switch off the ignition by turning the ignition key to the **OFF**  $\otimes$  position.
- Remove the black ignition key.
- Insert the orange programming key in the ignition lock.
- Switch on the ignition by turning the orange programming key to the **ON** position  $\bigcirc$ .
  - ✓ **FI** Warning lamp <sup>⊕</sup> (**MIL**) lights up, switches off, and then starts to flash.





- ✓ Immobilizer indicator lamp ⓐ lights up, switches off briefly and flashes; the number of flashes equals the number of functional black ignition keys including the orange programming key. In this case, twice.
- Switch off the ignition by turning the orange programming key to the **OFF** position  $\otimes$ .
- Pull out the programming key.
  - ✓ The lost black ignition key is deactivated.
  - ✓ The existing black ignition key is reactivated.

### Loss of both black ignition keys (no black ignition key available):

This procedure is important to prevent misuse of the lost black ignition key.

- Press the emergency OFF switch into the position ∩.

- Insert the orange programming key in the ignition lock.
- Switch on the ignition by turning the orange programming key to the **ON** position  $\bigcirc$ .
  - FI Warning lamp (I) (MIL) lights up, switches off, and then starts to flash.
  - ✓ Immobilizer indicator lamp <sup>ⓐ</sup> lights up.
- Switch off the ignition by turning the orange programming key to the **OFF** position  $\otimes$ .
- Switch on the ignition by turning the orange programming key to the **ON** position  $\bigcirc$ .
  - ✓ **FI** Warning lamp <sup>⊕</sup> (**MIL**) lights up, switches off, and then starts to flash.
  - ✓ Immobilizer indicator lamp <sup>®</sup> lights up, switches off briefly and flashes; the number of flashes equals the number of functional black ignition keys including the orange programming key. In this case once, since all black ignition keys are deactivated.

- Switch off the ignition by turning the orange programming key to the **OFF** position  $\otimes$ .
- Pull out the programming key.
  - ✓ All black ignition keys are deactivated.
- Order a new black ignition key according to the key number on the **KEYCODECARD** and activate it.


#### Activating the ignition key:

- Press the emergency OFF switch into the position  $\bigcirc.$
- Insert the orange programming key in the ignition lock.
- Switch on the ignition by turning the orange programming key to the **ON** position  $\bigcirc$ .
  - ✓ **FI** Warning lamp <sup>⊕</sup> (**MIL**) lights up, switches off, and then starts to flash.
  - ✓ Immobilizer indicator lamp <sup>ⓐ</sup> lights up.
- Switch off the ignition by turning the orange programming key to the OFF position ∞.
- Pull out the programming key.
- Insert the black ignition key in the ignition lock.
- Switch on the ignition by turning the ignition key to the  $\textbf{ON} \bigcirc$  position.
  - ✓ **FI** Warning lamp <sup>⊕</sup> (**MIL**) lights up, switches off, and then starts to flash.
  - Immobilizer indicator lamp 

     lights up, switches off briefly, and lights up again.
- Switch off the ignition by turning the ignition key to the  $OFF \otimes$  position.
- Remove the black ignition key.
- To activate further ignition keys, repeat the last 4 steps with the respective ignition key.
- Insert the orange programming key in the ignition lock.
- Switch on the ignition by turning the orange programming key to the **ON** position  $\bigcirc$ .
  - ✓ FI Warning lamp <sup>⊕</sup> (MIL) lights up, switches off, and then starts to flash.

- Immobilizer indicator lamp 
   lights up, switches off briefly and flashes; the number of flashes equals the number of functional black ignition keys including the orange programming key.
- Switch off the ignition by turning the orange programming key to the **OFF** position  $\otimes$ .
- Pull out the programming key.
  - ✓ All black ignition keys are activated included in this job sequence are activated.

### **Cooling system**



The water pump **1** in the engine forces the coolant to flow.

The pressure in the cooling system resulting from heat is regulated by a valve in the radiator cap. This permits the specified coolant temperature without causing any malfunctions.

125 °C (257 °F)

Cooling takes place by means of the air stream and a radiator fan, which is controlled by a thermoswitch.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

The heat expansion causes the surplus coolant to flow into the compensating tank **2**. When the temperature falls, this surplus coolant is sucked back into the cooling system.

### Checking the antifreeze and coolant level



## Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

– Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



#### Warning

Danger of poisoning Coolant is poisonous and a health hazard.

Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact
a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately.
Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

#### Condition

The engine is cold.

- Stand the motorcycle upright on a horizontal surface.
- Remove radiator cap ① and plug ② from the compensating tank.
- Check the coolant antifreeze.

−25... −45 °C (−13... −49 °F)

- » If the coolant antifreeze does not meet specifications:
  - Correct the coolant antifreeze.
- Check the coolant level in the compensating tank.

The coolant level must be between the upper marking ③ and lower marking ④.


- » If the coolant level in the compensating tank does not meet specifications, but the tank is not empty:
  - Add coolant to the upper marking.


#### Alternative 1

Coolant (\* p. 194)

#### Alternative 2

```
Coolant (mixed ready to use) (* p. 194)
```





- » If there is no coolant in the compensating tank:
  - Check the cooling system for leaks.



- Fill/bleed the cooling system. ◀ (♥ p. 148)
- Mount cap ② of the compensating tank.
- Check the coolant level in the radiator.

The radiator must be completely filled.

- » If the coolant level does not meet specifications:
  - Correct the coolant level and determine the reason for the coolant loss.

#### Alternative 1

Coolant (\* p. 194)

#### Alternative 2

Coolant (mixed ready to use) (\* p. 194)

- $\, * \,$  If more coolant needed to be added than the specified value:  $\, > 0.50$  l (> 0.53 qt.)
  - Fill/bleed the cooling system. ◀ (☞ p. 148)
- Mount radiator cap **①**.

### Checking the coolant level in the compensating tank



### Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.


Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine
and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



#### Warning

Danger of poisoning Coolant is poisonous and a health hazard.

 Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



#### Condition

The engine is cold. The radiator is completely full.

- Stand the motorcycle on a horizontal surface.
- Check the coolant level in the compensating tank **①**.

The coolant level must be between the upper marking  ${f Q}$  and lower marking  ${f S}$ .

- » If the coolant level in the compensating tank does not meet specifications, but the tank is not empty:
  - Remove the compensating tank cap.
  - Add coolant to the upper marking.

#### Alternative 1

Coolant (\* p. 194)

#### Alternative 2

Coolant (mixed ready to use) (\* p. 194)

- Mount the cap of the compensating tank.
- » If there is no coolant in the compensating tank:
  - Check the cooling system for leaks.

#### Info

Do not start up the motorcycle!

− Fill/bleed the cooling system. ◄ (♥ p. 148)

### Draining the coolant 🔧



### Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.


Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine
and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



#### Warning

Danger of poisoning Coolant is poisonous and a health hazard.


 Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



- Reset the fuel tank. (
   p. 83)
- Place a suitable container under the radiator.
- Remove radiator cap **1**.
- Remove screw 2.
- Completely drain the coolant.
- Mount screw **2** with a new seal ring and tighten it.

Guideline

Remaining chassis screws	M6	10 Nm (7.4 lbf ft)
Remaining chassis screws	IVIO	



- Place a suitable container under the engine.
- Remove screw 3.
- Completely drain the coolant.
- Mount screw **3** with a new seal ring and tighten it.

Guideline

Screw, water pump cover M6 10 Nm (7.4 lbf ft)
---


### Filling/bleeding the cooling system 🔌




### Warning


Danger of poisoning Coolant is poisonous and a health hazard.

 Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



- Reset the fuel tank. (
   p. 83)
- Ensure that the drain plug on the radiator and the water pump cover are tightened.
- Remove bleeder screw ①.





Position the vehicle as shown and secure it against rolling. Height difference @ must be reached.

Guideline

leight difference 🚯	50 cm (19.7 in)

### Info

To make sure that all of the air can escape from the cooling system, raise the front of the vehicle. A poorly bled cooling system is less effective at cooling and the engine can overheat.

Remove the radiator cap and pour in coolant until it emerges without bubbles at the vent hole, and then immediately mount and tighten the bleeder screw  $\mathbf{0}$ .

#### Alternative 1

Coolant (\* p. 194)

#### Alternative 2

Coolant (mixed ready to use) ( p. 194)

- Fill the radiator completely with coolant. Mount the radiator cap.
- Lean the vehicle on the side stand
- Check the coolant level in the compensating tank. (\* p. 145)


Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and run it until it reaches operating temperature.

- ✓ Six bars of the temperature display light up.
- Stop the engine and allow it to cool down.
- When the engine is cool, check the coolant level in the radiator and add coolant if necessary.
- Check the coolant level in the compensating tank. (\* p. 145)
- Position the fuel tank. (\* p. 84)

### Checking the play in the throttle cable



- Move the handlebar to the straight-ahead position. Move the throttle grip backwards and forwards to ascertain the play in the throttle cable.

Play in throttle cable3 5 mm (0.12 0.2 in)
--

- » If the throttle cable play does not meet specifications:
  - Adjust the play in the throttle cable. 

     (\* p. 152)

### Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
  - Adjust the play in the throttle cable. 

     (\* p. 152)

### Adjusting the play in the throttle cable 🔌



- Move the handlebar to the straight-ahead position.
- Use the KTM diagnostics tool to set the throttle stepper motor to the basic position.
- Loosen counter nut **①**.
- Set the play in the throttle cable by turning adjusting screw ②.
   Guideline

Play in throttle cable	3 5 mm (0.12 0.2 in)
------------------------	----------------------

Tighten counter nut ①.

### Ignition curve plug-in connector



The plug-in connection is located under the seat in front of the fuse box. By disconnecting the plug-in connector, the ignition curve for fuel with an octane rating below 95 (ROZ 95/RON 95/PON 91) is activated. While the engine will have a slightly lower power output, this setting prevents engine damage by hindering spark knocking due to poor fuel quality.

#### **Possible states**

- Plug-in connector disconnected Fuel with an octane rating of 80 to 94 (RON) can be used for one tank full.
- Plug-in connector connected Fuel with an octane rating of 95 or higher can be used.

### Adjusting the ignition curve to the fuel quality

- Switch off the ignition by turning the ignition key to the **OFF**  $\otimes$  position.

#### To activate the ignition curve for low octane fuel:

#### Note

**Engine damage** Low-quality fuel damages the engine.

- Operate the vehicle with fuel with an octane rating below 95 (ROZ 95 / RON 95 / PON 91) for no more than one tank full.
- The ignition curve must be adjusted to low octane fuel.
- Disconnect plug-in connector.
  - Plug-in connector disconnected Fuel with an octane rating of 80 to 94 (RON) can be used for one tank full. (\* p. 152)


#### Activate the ignition curve for fuel with an octane rating of 95 or higher (ROZ 95/RON 95/PON 91):

Connect plug-in connector.

✓ Plug-in connector connected – Fuel with an octane rating of 95 or higher can be used. (♥ p. 152)

– Mount the seat. (🕶 p. 82)

### Checking the basic position of the shift lever




- Sit on the vehicle in the riding position and determine the distance () between the upper edge of your boot and the shift lever.

Distance between shift lever and upper	10 20 mm (0.39 0.79 in)
edge of boot	

- » If the distance does not meet specifications:
  - Adjust the basic position of the shift lever. 

     (\* p. 154)

### Adjusting the basic position of the shift lever 🔧



101173-10

Remove screw  $\mathbf{0}$  and remove shift lever  $\mathbf{2}$ .

- Clean gear teeth () of the shift lever and shift shaft.
- Mount the shift lever on the shift shaft in the required position and engage the gearing.

#### • Info The

The range of adjustment is limited.


The shift lever must not come into contact with any other vehicle components during the shift procedure.

- Mount and tighten screw.

#### Guideline

Screw, shift lever	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
--------------------	----	-----------------------	---------------------------

### Checking the engine oil level



# Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and run it until it reaches operating temperature.
  - ✓ Six bars of the temperature display light up.
- Switch off the engine.
- Park the motorcycle on a horizontal surface in a vertical position (not on the side stand).

#### Info

After switching off the engine, wait one minute before checking the level.

- Check the engine oil level at oil level viewer **①**.

The engine oil level must be between the upper marking **2** and lower marking **3**.

- » If the engine oil level is not at the specified level:
  - Add engine oil. (🕶 p. 162)

### Changing the engine oil and filter, cleaning the oil screens $\boldsymbol{A}$



- Drain the engine oil and filter, clean the oil screens. 🔌 (🕶 p. 156)
- Fill up with engine oil. 🔧 (🖛 p. 161)

### Draining the engine oil and filter, cleaning the oil screens 🔌



#### Warning

**Danger of scalding** Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.




### Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.


### Info


Drain the engine oil only when the engine is warm.




- Place a suitable container under the engine.
- Remove the oil drain plug **1** with the magnet and seal ring.
- Fully drain the engine oil out of the engine.

- Remove screws **2** and cover **3**.







- Pull oil screen **4** out of the engine case with pliers.



- Place a suitable container under the engine.
- Remove oil drain plug 6.
- Fully drain the engine oil out of the oil tank.
- Remove screws ③ and move oil line ⑦ to one side.







- Pull oil sieve <sup>(3)</sup> out of the oil tank.

- Remove screw connections **9** and move the oil line to one side.
- Remove screws. Take off oil filter cover **1** with the O-ring.
- Pull oil filter **1** out of the oil filter housing.

Circlip pliers reverse (51012011000)

- Completely drain the engine oil.
- Clean all oil screens and oil drain plugs with a magnet.
- Clean all sealing surfaces.








- Insert oil filter ①.
- Lubricate the O-ring of the oil filter cover.

Remaining engine screws	M5	6 Nm (4.4 lbf ft)	
Position the oil line. Mount and tighten scre	w cap <b>9</b> .		
Guideline			
Nut, oil line	M16x1.5	25 Nm (18.4 lbf ft)	

- Check seal ring **@** of the oil sieve for damage and correct seating.
- Insert oil sieve <sup>(3)</sup> into the oil tank.







- Position oil line **1**. Mount and tighten screws **3**.

Guideline

	Remaining engine screws	M6	10 Nm (7.4 lbf ft)	
<ul> <li>Mount oil drain plug S with the magnet and new seal and tighten.</li> </ul>				
	Guideline			
		M10 1 F		

Oil drain plug with magnet	M12x1.5	25 Nm (18.4 lbf ft)
----------------------------	---------	------------------------

 Mount oil drain plug 
 with the magnet and new seal ring and tighten. Guideline

Oil drain plug with magnet	M22x1.5	35 Nm (25.8 lbf ft)	
----------------------------	---------	------------------------	--

- Slide oil sieve **4** into the engine case with the **TOP** marking facing up.
- Check the form ring in cover <sup>(3)</sup> for damage and correct seating.
- Position the cover. Mount and tighten the screws. Guideline


Screw, clutch cover	M6	10 Nm (7.4 lbf ft)
---------------------	----	--------------------

160

# Filling up with engine oil 🔌

### lnfo

Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- The oil must be added in two steps.

Engine oil	3.80 I (1.004 US gal)	External temperature: ≥ 0 °C (≥ 32 °F)	Engine oil (SAE 10W/50) (• p. 195)
		External temperature: < 0 °C (< 32 °F)	Engine oil (SAE 5W/40) (& p. 195)

- Remove plug ① and add engine oil to the top marking ②.
- Mount the plug.



### Danger

**Danger of poisoning** Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and run it until it reaches operating temperature.
  - ✓ Six bars of the temperature display light up.
- Check the lubrication system for leaks.
- Switch off the engine.
- Park the motorcycle on a horizontal surface in a vertical position (not on the side stand).


161

- Remove the plug.
- Add engine oil to the top marking **2**.
- Mount the plug.

### Adding engine oil

### Info

Too little engine oil or poor-quality engine oil results in premature wear to the engine. The engine oil level must be corrected when the engine is warm.



Remove plug ① and add engine oil to the top marking ②.

### Condition

External temperature:  $\geq$  0 °C ( $\geq$  32 °F)

Engine oil (SAE 10W/50) (\* p. 195)

#### Condition

```
External temperature: < 0 °C (< 32 °F)
```

Engine oil (SAE 5W/40) (\* p. 195)

# • Info

For optimal performance of the engine oil, do not mix different types of engine oil.

We recommend changing the engine oil, if necessary.

Mount the plug.

# **CLEANING, CARE**

### **Cleaning motorcycle**

#### Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

Never clean the vehicle with high-pressure cleaning equipment or a strong water-jet. The excessive pressure can penetrate electrical
components, socket connects, throttle cables, and bearings, etc., and can damage or destroy these parts.


# Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

### Info

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period. Avoid direct sunshine on the motorcycle during cleaning.



- Close off the exhaust system to keep water from entering.
- Remove coarse dirt particles with a gentle spray of water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a paintbrush.

Motorcycle cleaner (\* p. 199)

### Info

•

Clean the vehicle using warm water containing normal motorcycle cleaner and a soft sponge.

If the vehicle was operated in road salt, clean it with cold water. Warm water would enhance the corrosive effects of salt.

- After the motorcycle has been thoroughly cleaned with a gentle jet of water, it should be dried with compressed air and a cloth.

# Warning

Danger of accidents Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.
- After cleaning, ride the vehicle a short distance until the engine warms up, applying the brakes occasionally.

#### Info

•

- The heat produced causes water at inaccessible positions in the engine and on the brakes to evaporate.
- After the motorcycle has cooled off, lubricate all moving parts and bearings.
- Clean the chain. (\* p. 86)
- Treat bare metal parts (except for brake discs and exhaust system) with anti-corrosion materials.

Cleaning and preserving materials for metal, rubber and plastic (\* p. 198)

- Treat all painted parts with a mild paint polish.

High-luster polish for paint (\* p. 198)

Oil the ignition/steering lock, tank lock, and seat lock.

Universal oil spray (\* p. 199)


# CLEANING, CARE

### Protective treatment for winter operation

### Info

If you use the motorcycle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.

If the vehicle was operated in road salt, clean it with cold water. Warm water would enhance the corrosive effects of salt.



- Clean the motorcycle. (🕶 p. 163)
- Treat the engine, the swingarm, and all other bare or galvanized parts (except brake discs) with a wax-based anti-corrosion substance.

### Info

i


- To prevent serious reduction of the braking efficiency, make sure no anti-corrosion substance gets on to the brake discs. After riding on salted roads, thoroughly wash the motorcycle with cold water and dry it well.
- Clean the chain. (🕶 p. 86)

# STORAGE

### Storage

### Info

If you want to garage the motorcycle for a longer period, take the following actions. Before storing the motorcycle, check all parts for function and wear. If service, repairs or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- Make sure the fuel tanks are as empty as possible so that you can fill up with fresh fuel when you put the motorcycle back into operation.
- Clean the motorcycle. (\* p. 163)
- Change the engine oil and filter, clean the oil screens. ◀ (♥ p. 156)
- Check the antifreeze and coolant level. (\* p. 143)
- Check the tire air pressure. (\* p. 112)
- Remove the battery. 🔌 (🕶 p. 114)
- Recharge the battery. 🔌 (🕶 p. 116)

#### Guideline

Storage temperature of battery without	0 35 °C (32 95 °F)
direct sunshine	

 Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

## Info

- KTM recommends raising the motorcycle.
- Raise the motorcycle with the front wheel stand. (\* p. 79)


- Cover the motorcycle with a tarp or cover that is permeable to air.

#### Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and exhaust system to rust.

### Preparing for use after storage



- Take the motorcycle off of the front wheel stand. (\* p. 79)
- Take the motorcycle off of the rear wheel stand. (\* p. 80)
- − Recharge the battery. ◀ (♥ p. 116)
- Install the battery. 🔧 (🕶 p. 115)
- Set the clock. (\* p. 40)
- Refuel. (\* p. 65)
- Take a test ride.

# TROUBLESHOOTING

Faults	Possible cause	Action
The engine does not turn when the starter button is pressed	Operating error	<ul> <li>Carry out the start procedure. (</li></ul>
	Battery discharged	– Recharge the battery. 🔌 (🕶 p. 116)
		<ul> <li>Check the closed current.</li> </ul>
	IGNITION, FUEL PUMP, or POWER RELAY fuse blown	<ul> <li>Change the fuses of individual power consumers.</li> <li>(* p. 120)</li> </ul>
	Main fuse burned out	- Change the main fuse. ( <b>*</b> p. 118)
	Ignition/steering lock or emergency	- Check the emergency OFF switch. 🔧
	OFF switch defective	– Check the ignition/steering lock. 🔧
	Defect in safety start system	– Check the safety start system. 🔧
	Immobilizer control unit not activated	– Activate the immobilizer control unit. 🔧
	Malfunction in CAN bus communica- tion	- Check the CAN bus communication.
	Combination instrument defective	<ul> <li>Check the combination instrument. </li> </ul>
	Control unit for electric start lock defective	<ul> <li>Check the control unit of the electric start lock.</li> </ul>
Engine turns only if the clutch lever is	The vehicle is in gear	- Shift the transmission to neutral.
drawn	Defect in safety start system	– Check the safety start system. 🔧
Engine turns although a gear is engaged	Defect in safety start system	<ul> <li>Check the safety start system.</li> </ul>
Engine turns but does not start	Coupling of fuel hose connection not connected	<ul> <li>Reconnect coupling of fuel hose connection.</li> </ul>
	Socket connector of cable harness oxi- dized	<ul> <li>Clean the socket connector and treat it with con- tact spray.</li> </ul>
	Defect in fuel injection system	<ul> <li>Read out the fault memory using the KTM diag- nostics tool.</li> </ul>

# TROUBLESHOOTING

Faults	Possible cause	Action
Engine has too little power	Air filter very dirty	– Change the air filter. 🔌
	Defect in fuel injection system	<ul> <li>Read out the fault memory using the KTM diag- nostics tool.</li> </ul>
	Ignition curve for low octane fuel activated	<ul> <li>Refuel with fuel with an octane rating of 95 or higher.</li> </ul>
		<ul> <li>Connect plug-in connector.</li> </ul>
Engine overheats	Too little coolant in cooling system	<ul> <li>Check the cooling system for leaks.</li> </ul>
		<ul> <li>Check the antifreeze and coolant level.</li> <li>(* p. 143)</li> </ul>
	Radiator fins very dirty	<ul> <li>Clean radiator fins.</li> </ul>
	Foam formation in cooling system	- Drain the coolant. 🔌 (🕶 p. 147)
		− Fill/bleed the cooling system. ◄ (♥ p. 148)
	Buckled or damaged radiator hose	– Change the radiator hose. 🔧
	Fuse FAN blown	<ul> <li>Change the fuses of individual power consumers.</li> <li>(* p. 120)</li> </ul>
	Thermostat defective	- Check the thermostat. 🔺
	Defect in radiator fan system	– Check the radiator fan system. 🔧
	Air in cooling system	− Fill/bleed the cooling system. ◄ (◄ p. 148)
Warning lamp <b>FI</b> ( <b>MIL</b> ) lights up/flashes	Defect in fuel injection system	<ul> <li>Read out the fault memory using the KTM diag- nostics tool.</li> </ul>
Engine dies during a trip	Lack of fuel	– Refuel. (* p. 65)
	IGNITION, FUEL PUMP, or POWER RELAY fuse blown	<ul> <li>Change the fuses of individual power consumers.</li> <li>(* p. 120)</li> </ul>
High oil consumption	Engine oil level too high	- Check the engine oil level. (* p. 155)

# TROUBLESHOOTING

Faults	Possible cause	Action
High oil consumption	Engine oil too thin (low viscosity)	<ul> <li>Change the engine oil and filter, clean the oil screens. ▲ (♥ p. 156)</li> </ul>
Headlight and parking light are not functioning	Fuse H/L BEAM, POSITION blown	<ul> <li>Change the fuses of individual power consumers.</li> <li>(* p. 120)</li> </ul>
Turn signal, hazard warning flasher, brake light and horn are not functional	Fuse HORN, BRAKE LIGHT, SPEEDO blown	<ul> <li>Change the fuses of individual power consumers.</li> <li>(* p. 120)</li> </ul>
Battery discharged	Ignition not switched off when vehicle was parked	- Recharge the battery. 🔌 (🕶 p. 116)
	Battery is not charged by the alternator	– Check the charging voltage. 🔌
Combination instrument shows nothing in the display	Fuse ACC1, CLOCK blown	<ul> <li>Change the fuses of individual power consumers.</li> <li>(* p. 120)</li> </ul>
Speedometer in combination instru- ment not functioning	Wiring harness of wheel revolution counter damaged or plug-in connec- tor oxidized	<ul> <li>Check the wheel speed sensor.</li> </ul>

# IMMOBILIZER BLINK CODE

Blink code of immobilizer indica- tor lamp	
	12 Immobilizer indicator lamp flashes 1x short, 1 second pause, 2x short
Error level condition	All ignition keys inactive
Blink code of immobilizer indica- tor lamp	
	13 Immobilizer indicator lamp flashes 1x short, 1 second pause, 3x short
Error level condition	Malfunction, antenna of immobilizer control unit
Blink code of immobilizer indica- tor lamp	14 Immobilizer indicator lamp flashes 1x short, 1 second pause, 4x short
Error level condition	Malfunction in transponder of black ignition key
Blink code of immobilizer indica- tor lamp	15 Immobilizer indicator lamp flashes 1x short, 1 second pause, 5x short
Error level condition	Black ignition key inactive
Blink code of immobilizer indica- tor lamp	16 Immobilizer indicator lamp flashes 1x short, 1 second pause, 6x short
Error level condition	Malfunction, encryption, immobilizer control unit to black ignition key

\_\_\_\_\_

# IMMOBILIZER BLINK CODE

Blink code of immobilizer indica- tor lamp		
	21 Immobilizer indicator lamp flashes 2x short, 1 second pause, 1x short	
Error level condition	Immobilizer control unit not activated	
Blink code of immobilizer indica- tor lamp		
	31 Immobilizer indicator lamp flashes 3x short, 1 second pause, 1x short	
Error level condition	Malfunction, encryption query from EFI control unit to immobilizer control unit	
Blink code of immobilizer indica- tor lamp		
	32 Immobilizer indicator lamp flashes 3x short, 1 second pause, 2x short	
Error level condition	Malfunction in CAN bus communication	
Blink code of immobilizer indica- tor lamp	Columnative indicator lana flasher (u short	
	60 Immobilizer indicator lamp flashes 6x short	
Error level condition	E <sup>2</sup> PROM malfunction	

\_\_\_\_\_

Blink code FI of warning lamp (MIL)	FI
	02 Warning lamp FI (MIL) flashes 2x short
Error level condition	Circuit ignition pulse generator - circuit fault
Blink code FI of warning lamp (MIL)	F
	06 Warning lamp FI (MIL) flashes 6x short
Error level condition	Throttle valve sensor circuit A - input signal too low
	Throttle valve sensor circuit A - input signal too high
Blink code FI of warning lamp (MIL)	FI
	07 Warning lamp FI (MIL) flashes 7x short
Error level condition	Throttle position sensor circuit B - input signal too low
	Throttle position sensor circuit B - input signal too high
Blink code FI of warning lamp (MIL)	F
	09 Warning lamp FI (MIL) flashes 9x short
Error level condition	Manifold absolute pressure sensor cylinder 1 - input signal too low
	Manifold absolute pressure sensor cylinder 1 - input signal too high
Blink code FI of warning lamp (MIL)	F
	11 Warning lamp FI (MIL) flashes 1x long, 1x short
Error level condition	Manifold absolute pressure sensor cylinder 2 - input signal too low
	Manifold absolute pressure sensor cylinder 2 - input signal too high

Blink code FI of warning lamp (MIL)	(FI)	
	12 Warning lamp FI (MIL) flashes 1x long, 2x short	
Error level condition	Coolant temperature sensor - input signal too low	
	Coolant temperature sensor - input signal too high	
Blink code FI of warning lamp (MIL)	F	
	13 Warning lamp FI (MIL) flashes 1x long, 3x short	
Error level condition	Intake air temperature sensor - input signal too low	
	Intake air temperature sensor - input signal too high	
Blink code FI of warning lamp (MIL)	F	
	14 Warning lamp FI (MIL) flashes 1x long, 4x short	
Error level condition	Ambient air pressure sensor - input signal too low	
	Ambient air pressure sensor - input signal too high	
Blink code FI of warning lamp (MIL)	F	
	15 Warning lamp FI (MIL) flashes 1x long, 5x short	
Error level condition	Rollover sensor (A/D type) - input signal too low	
	Rollover sensor (A/D type) - input signal too high	
Blink code FI of warning lamp (MIL)	F	
	17 Warning lamp FI (MIL) flashes 1x long, 7x short	
Error level condition	Lambda sensor cylinder 1, sensor 1 - circuit fault	

Blink code FI of warning lamp (MIL)	FI
	18 Warning lamp FI (MIL) flashes 1x long, 8x short
Error level condition	Lambda sensor cylinder 2, sensor 1 - circuit fault
Blink code FI of warning lamp (MIL)	FI
	24 Warning lamp <b>FI (MIL</b> ) flashes 2x long, 4x short
Error level condition	Power supply - circuit fault
Blink code FI of warning lamp (MIL)	FI
	25 Warning lamp <b>FI (MIL</b> ) flashes 2x long, 5x short
Error level condition	Side stand (A/D type) - malfunction in circuit
Blink code FI of warning lamp (MIL)	F
	33 Warning lamp <b>FI (MIL</b> ) flashes 3x long, 3x short
Error level condition	Injector cylinder 1 - circuit fault
Blink code FI of warning lamp (MIL)	F
	34 Warning lamp FI (MIL) flashes 3x long, 4x short
Error level condition	Injector cylinder 2 - circuit fault

Blink code FI of warning lamp (MIL)	(FI)
	37 Warning lamp FI (MIL) flashes 3x long, 7x short
Error level condition	Ignition coil 1, cylinder 1 - circuit fault
Blink code FI of warning lamp (MIL)	F
	38 Warning lamp FI (MIL) flashes 3x long, 8x short
Error level condition	Ignition coil 1, cylinder 2 - circuit fault
Blink code FI of warning lamp (MIL)	FI
	41 Warning lamp <b>FI (MIL</b> ) flashes 4x long, 1x short
Error level condition	Fuel pump control - interruption/short circuit to ground
	Fuel pump control - input signal too high
Blink code FI of warning lamp (MIL)	F
	45 FI Warning lamp (MIL) flashes 4x long, 5x short
Error level condition	Heating lambda sensor cylinder 1, sensor 1 - interruption/short circuit to ground
	Heating lambda sensor cylinder 1, sensor 1 - input signal too high
Blink code FI of warning lamp (MIL)	F
	46 Warning lamp <b>FI (MIL</b> ) flashes 4x long, 6x short
Error level condition	Heating lambda sensor cylinder 2, sensor 1 - interruption/short circuit to ground
	Heating lambda sensor cylinder 2, sensor 1 - input signal too high

Blink code FI of warning lamp (MIL)	(FI)	
	49 Warning lamp <b>FI</b> ( <b>MIL</b> ) flashes 4x long, 9x short	
Error level condition	Motor drive circuit A - circuit fault	
Blink code FI of warning lamp (MIL)	F	
	50 Warning lamp FI (MIL) flashes 5x long	
Error level condition	Motor drive circuit B - circuit fault	
Blink code FI of warning lamp (MIL)	(F)	
	53 Warning lamp FI (MIL) flashes 5x long, 3x short	
Error level condition	Fuel evaporation system - short circuit to ground or open circuit	
	Fuel evaporation system - input signal too high	
Blink code FI of warning lamp (MIL)	F	
	54 Warning lamp FI (MIL) flashes 5x long, 4x short	
Error level condition	Secondary air valve - interruption/short circuit to ground	
	Secondary air valve - input signal too high	
Blink code FI of warning lamp (MIL)	F	
	68 Warning lamp FI (MIL) flashes 6x long, 8x short	
Error level condition	Manifold absolute pressure sensor cylinder 1 - connection leaks	

Blink code FI of warning lamp (MIL)	F
	69 Warning lamp FI (MIL) flashes 6x long, 9x short
Error level condition	Manifold absolute pressure sensor cylinder 2 - connection leaks
Blink code FI of warning lamp (MIL)	E) 81 Warning lamp <b>FI (MIL</b> ) flashes 8x long, 1x short
Error level condition	Immobilizer control unit - circuit fault
Blink code FI of warning lamp (MIL)	FI         91 Warning lamp FI (MIL) flashes 9x long, 1x short
Error level condition	Malfunction in CAN bus communication

# TECHNICAL DATA - ENGINE

Design	2-cylinder 4-stroke Otto motor, 75° V arrangement, water-cooled
Displacement	999 cm <sup>3</sup> (60.96 cu in)
Stroke	62.4 mm (2.457 in)
Bore	101 mm (3.98 in)
Compression ratio	11.5:1
Control	DOHC, 4 valves per cylinder, chain-driven
Valve - diameter	
Exhaust	33 mm (1.3 in)
Intake	38 mm (1.5 in)
Valve clearance	
Exhaust at: 20 °C (68 °F)	0.25 0.30 mm (0.0098 0.0118 in)
Intake at: 20 °C (68 °F)	0.10 0.15 mm (0.0039 0.0059 in)
Crankshaft bearing	Sleeve bearing
Conrod bearing	Sleeve bearing
Piston	Forged light alloy
Piston ring	1 L-ring, 1 tapered compression piston ring, 1 oil scraper ring
Engine lubrication	Dry sump lubrication system with two rotor pumps
Primary transmission	35:67
Clutch	Multidisc clutch in oil bath/hydraulically activated
Transmission	6-gears, claw-shifted
Transmission ratio	
1st gear	12:35
2nd gear	15:32
3rd gear	18:30
4th gear	20:27

# **TECHNICAL DATA - ENGINE**

5th gear	24:27	
6th gear	27:26	
Mixture preparation	Electronic fuel injection	
Ignition system	Contactless controlled fully electronic ignition with digital ignition adjustment	
Alternator	12 V, 450 W	
Spark plug	NGK LKAR8BI9	
Spark plug electrode gap	0.8 mm (0.031 in)	
Cooling	Water cooling, permanent circulation of coolant by water pump	
Idle speed	1,400 1,500 rpm	
Cold start device	Electric starter	

## Capacity- engine oil

Engine oil3.80   (1.004 US gal)	3.80 I (1.004 US gal)	External temperature: ≥ 0 °C (≥ 32 °F)	Engine oil (SAE 10W/50) (  • p. 195)
		External temperature: < 0 °C (< 32 °F)	Engine oil (SAE 5W/40) (• p. 195)

Capacity - coolant		
Coolant	2.30 I (2.43 qt.)	Coolant (🕶 p. 194)
		Coolant (mixed ready to use) ( P. 194)

Hose clip, intake flange	M4	1.5 Nm (1.11 lbf ft)	-
Oil jet	M4	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Remaining engine screws	M5	6 Nm (4.4 lbf ft)	-
Screw, bearing retainer	M5	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, connecting angle on valve cover	M5	3 Nm (2.2 lbf ft)	Loctite <sup>®</sup> 243™
Screw, gear sensor	M5	3 Nm (2.2 lbf ft)	Loctite <sup>®</sup> 243™
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Nut, cylinder head	M6	8 Nm (5.9 lbf ft)	-
Plug, vacuum connection	M6	5 Nm (3.7 lbf ft)	Loctite <sup>®</sup> 243™
Remaining engine screws	M6	10 Nm (7.4 lbf ft)	-
Screw in alternator cover	M6	10 Nm (7.4 lbf ft)	-
Screw, bearing bolt in alternator cover	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, camshaft bearing support	M6	10 Nm (7.4 lbf ft)	-
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	-
Screw, clutch spring	M6	10 Nm (7.4 lbf ft)	-
Screw, engine case	M6	10 Nm (7.4 lbf ft)	-
Screw, freewheel holder	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, freewheel ring	M6	13 Nm (9.6 lbf ft)	Loctite <sup>®</sup> 648™
Screw, oil pump housing	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, pulse generator	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, shift lever	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, starter motor	M6	10 Nm (7.4 lbf ft)	-
Screw, stator	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™

Screw, valve cover	M6	10 Nm (7.4 lbf ft)	-
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	-
Screw, water pump wheel	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Stud, cylinder head in cylinder	M6		Loctite <sup>®</sup> 243™
Stud, cylinder head in engine case	M6	10 Nm (7.4 lbf ft)	-
Vacuum connection	M6	5 Nm (3.7 lbf ft)	Loctite <sup>®</sup> 243™
Oil jet	M6x0.75	4 Nm (3 lbf ft)	Loctite <sup>®</sup> 243™
Bearing bolt, timing chain guide rail	M8	15 Nm (11.1 lbf ft)	Loctite <sup>®</sup> 243™
Bearing bolt, timing chain tensioning rail	M8	20 Nm (14.8 lbf ft)	Loctite <sup>®</sup> 243™
Screw, camshaft bearing support	M8	Step 1 10 Nm (7.4 lbf ft) Step 2 18 Nm (13.3 lbf ft)	-
Screw, clutch cover	M8	15 Nm (11.1 lbf ft)	-
Screw, cylinder head	M8	Step 1 18 Nm (13.3 lbf ft) Step 2 23 Nm (17 lbf ft)	Loctite <sup>®</sup> 243™
Stud, exhaust flange	M8	15 Nm (11.1 lbf ft)	-
Bearing bolt, timing gears	M10	30 Nm (22.1 lbf ft)	-
Nut, cylinder head (exterior)	M10	Step 1 23 Nm (17 lbf ft) Step 2	Only applies when using: Box wrench attachment 13mm (60029081000)
		34 Nm (25.1 lbf ft)	Lubricated with engine oil

Nut, cylinder head on chain shaft	M10	Step 1 25 Nm (18.4 lbf ft) Step 2 38 Nm (28 lbf ft)	Lubricated with engine oil
Plug, clutch lubrication	M10	15 Nm (11.1 lbf ft)	-
Stud, cylinder head in engine case	M10	20 Nm (14.8 lbf ft)	-
Oil pressure sensor	M10x1	10 Nm (7.4 lbf ft)	-
Screw, conrod bearing	M1Ox1	Step 1 25 Nm (18.4 lbf ft) Step 2 30 Nm (22.1 lbf ft) Step 3 60°	_
Spark plug	M12x1.25	18 Nm (13.3 lbf ft)	-
Coolant temperature sensor	M12x1.5	12 Nm (8.9 lbf ft)	-
Plus, cylinder head (2nd cylinder)	M12x1.5	25 Nm (18.4 lbf ft)	-
Plug, oil filter housing	M14x1.5	15 Nm (11.1 lbf ft)	Loctite <sup>®</sup> 243™
Bleeder flange, alternator cover	M16x1.5	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Plug, timing-chain tensioner	M16x1.5	20 Nm (14.8 lbf ft)	-
Rotor screw	M16x1.5	150 Nm (110.6 lbf ft)	Loctite <sup>®</sup> 243™
Nut, balancer shaft	M20x1.5	120 Nm (88.5 lbf ft)	Loctite <sup>®</sup> 243™
Nut, engine sprocket	M20x1.5	100 Nm (73.8 lbf ft)	Loctite <sup>®</sup> 243™
Screw-in fitting, cooling system	M20x1.5	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 577
Nut, inner clutch hub	M22x1.5	130 Nm (95.9 lbf ft)	Loctite <sup>®</sup> 243™
Oil drain plug with magnet	M22x1.5	35 Nm (25.8 lbf ft)	-
Screw in alternator cover	M24x1.5	8 Nm (5.9 lbf ft)	-

Nut, primary gear	M33LHx1.5	130 Nm (95.9 lbf ft)	Loctite <sup>®</sup> 243™
-------------------	-----------	----------------------	---------------------------

## **TECHNICAL DATA - CHASSIS**

Frame	Lattice frame made of chrome molybdenum steel tubing, powder-
	coated
Fork	WP Suspension Up Side Down 4860 ROMA PA
Shock absorber	WP Suspension 4618 BAVP DCC
Suspension travel	·
Front	160 mm (6.3 in)
Rear	180 mm (7.09 in)
Brake system	·
Front	Double disc brake with radially screwed four-piston brake calipers, float-mounted brake discs
Rear	Single disc brake with dual-piston brake caliper, rigid-mounted brake disc
Brake discs - diameter	
Front	305 mm (12.01 in)
Rear	240 mm (9.45 in)
Brake discs - wear limit	·
Front	4.5 mm (0.177 in)
Brake disc - wear limit	·
Rear	4.5 mm (0.177 in)
Tire air pressure, solo	
Front	2.2 bar (32 psi)
Rear	2.2 bar (32 psi)
Tire air pressure with passenger/full payload	·
Front	2.4 bar (35 psi)
Rear	2.5 bar (36 psi)

# **TECHNICAL DATA - CHASSIS**

Secondary drive ratio	17:41
Chain	5/8 x 5/16" X-ring
Steering head angle	65.6°
Wheelbase	1,505±15 mm (59.25±0.59 in)
Seat height, unloaded	875 mm (34.45 in)
Ground clearance, unloaded	195 mm (7.68 in)
Weight without fuel, approx.	189 kg (417 lb.)
Maximum permissible front axle load	160 kg (353 lb.)
Maximum permissible rear axle load	250 kg (551 lb.)
Maximum permissible total weight	400 kg (882 lb.)

Battery	YTZ14S	Battery voltage: 12 V Nominal capacity: 11.2 Ah maintenance-free
Fuse	58011109110	10 A
Fuse	58011109115	15 A
Fuse	58011109130	30 A

## Lighting equipment

Low beam/high beam	H4/socket P43t	12 V 60/55 W
Parking light	W5W/socket W2.1x9.5d	12 V 5 W
Instrument lights and indicator lamps	LED	
Turn signal	RY10W/socket BAU15s	12 V 10 W

## **TECHNICAL DATA - CHASSIS**

Tail light	W5W/socket W2.1x9.5d	12 V 5 W
Brake light	P21W/socket BA15s	12 V 21 W
License plate lamp	W5W/socket W2.1x9.5d	12 V 5 W

### Tires

Front tire	Rear tire
120/70 ZR 17 M/C 58W TL Pirelli DRAGON SUPERCORSA PRO	180/55 ZR 17 M/C 73W TL Pirelli DRAGON SUPERCORSA PRO
Additional information is available in the Service section under: http://www.ktm.com	

## Capacity - fuel

Total fuel tank capacity, approx.	15 I (4 US gal)	Super unleaded (ROZ 95 / RON 95 / PON 91) (* p. 197)
Fuel reserve, approx.		3.5   (3.7 qt.)

# TECHNICAL DATA - FORK

Fork part number		14.18.7E.21		
Fork		WP Suspension Up Side Down 4860 ROMA PA		
Compression damping				
Comfort		20 clicks		
Standard		15 clicks		
Sport		10 clicks		
Full payload		10 clicks		
Rebound damping				
Comfort		20 clicks		
Standard		15 clicks		
Sport		10 clicks		
Full payload		10 clicks		
Spring preload - Preload Adjust	ster			
Comfort		5 turns		
Standard		5 turns		
Sport		3 turns		
Full payload		3 turns		
Spring length with preload spacer(s)		386 mm (15.2 in)		
Spring rate				
Medium (standard)		7.5 N/mm (42.8 lb/in)		
Fork length		877 mm (34.53 in)		
Air chamber length		100±20 mm (3.94±0.79 in)		
Fork oil per fork leg	750 ml (25.36 fl. oz.)	Fork oil (SAE 5) (🕶 p. 196)		

# **TECHNICAL DATA - SHOCK ABSORBER**

Shock absorber part number	15.18.7E.03	
Shock absorber	WP Suspension 4618 BAVP DCC	
Compression damping, low-speed	· · · · · ·	
Comfort	25 clicks	
Standard	20 clicks	
Sport	15 clicks	
Full payload	15 clicks	
Compression damping, high-speed		
Comfort	2 turns	
Standard	1.5 turns	
Sport	1 turn	
Full payload	1 turn	
Rebound damping		
Comfort	20 clicks	
Standard	15 clicks	
Sport	10 clicks	
Full payload	10 clicks	
Spring preload		
Comfort	11 mm (0.43 in)	
Standard	11 mm (0.43 in)	
Sport	11 mm (0.43 in)	
Full payload	13 mm (0.51 in)	
Spring rate	·	
Medium (standard)	140 N/mm (799 lb/in)	
Spring length	200 mm (7.87 in)	

# **TECHNICAL DATA - SHOCK ABSORBER**

Gas pressure	10 bar (145 psi)
Static sag	20 mm (0.79 in)
Fitted length	372 mm (14.65 in)
Shock absorber fluid	Shock absorber oil (SAE 2,5) (50180342S1) (* p. 196)

# TECHNICAL DATA - CHASSIS TIGHTENING TORQUES

Screw, rear side part	EJOT	Initial screw connection 3.3 Nm (2.43 lbf ft) Subsequent screw connec- tion 2 Nm (1.5 lbf ft)	-
Screw, side stand switch	M4	2 Nm (1.5 lbf ft)	Loctite <sup>®</sup> 243™
Remaining chassis screws	M5	5 Nm (3.7 lbf ft)	-
Screw, chain sliding guard	M5	5 Nm (3.7 lbf ft)	-
Screw, closure flange, fuel tank	M5	3.3 Nm (2.43 lbf ft)	-
Screw, engine oil level viewer	M5	3.3 Nm (2.43 lbf ft)	-
Screw, foot brake lever stub	M5	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Nut, tail light	M6	8 Nm (5.9 lbf ft)	-
Remaining chassis nuts	M6	15 Nm (11.1 lbf ft)	-
Remaining chassis screws	M6	10 Nm (7.4 lbf ft)	-
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, foot brake cylinder	M6	10 Nm (7.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, fuel pump	M6	6 Nm (4.4 lbf ft)	-
Screw, fuel tap	M6	6 Nm (4.4 lbf ft)	-
Screw, magnetic holder on side stand	M6	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, seat bracket, fuel tank	M6	3.3 Nm (2.43 lbf ft)	-
Screw, splash protector	M6	6 Nm (4.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, spoiler	M6	3.3 Nm (2.43 lbf ft)	-
Remaining chassis nuts	M8	30 Nm (22.1 lbf ft)	-
Remaining chassis screws	M8	25 Nm (18.4 lbf ft)	-
Screw, bottom triple clamp	M8	15 Nm (11.1 lbf ft)	-

# **TECHNICAL DATA - CHASSIS TIGHTENING TORQUES**

Screw, exhaust clamp on main silencer	M8	20 Nm (14.8 lbf ft)	-
Screw, exhaust clamp on manifold	M8	35 Nm (25.8 lbf ft)	-
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	-
Screw, front brake disc	M8	30 Nm (22.1 lbf ft)	Loctite <sup>®</sup> 243™
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	-
Screw, handrail	M8	20 Nm (14.8 lbf ft)	-
Screw, ignition lock (ratchet screw)	M8		Loctite <sup>®</sup> 243™
Screw, rear brake disc	M8	30 Nm (22.1 lbf ft)	Loctite <sup>®</sup> 243™
Screw, rear footrest bracket	M8	25 Nm (18.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, side stand holder	M8	25 Nm (18.4 lbf ft)	Loctite <sup>®</sup> 243™
Screw, steering stem	M8	20 Nm (14.8 lbf ft)	-
Screw, top triple clamp	M8	20 Nm (14.8 lbf ft)	-
Engine carrying screw	M10	45 Nm (33.2 lbf ft)	-
Remaining chassis nuts	M10	50 Nm (36.9 lbf ft)	-
Remaining frame bolts	M10	45 Nm (33.2 lbf ft)	-
Screw, handlebar support	M10	20 Nm (14.8 lbf ft)	-
Screw, side stand	M10	35 Nm (25.8 lbf ft)	Loctite <sup>®</sup> 243™
Screw, side stand bracket	M10	45 Nm (33.2 lbf ft)	Loctite <sup>®</sup> 243™
Screw connection, rear hub shock absorber/rear sprocket	M10x1.25	50 Nm (36.9 lbf ft)	Loctite <sup>®</sup> 243™
Screw, front brake caliper	M10x1.25	45 Nm (33.2 lbf ft)	Loctite <sup>®</sup> 243™
Screw, lower subframe	M10x1.25	45 Nm (33.2 lbf ft)	Loctite <sup>®</sup> 243™
Screw, upper subframe	M10x1.25	45 Nm (33.2 lbf ft)	Loctite <sup>®</sup> 243™
Oil drain plug with magnet	M12x1.5	25 Nm (18.4 lbf ft)	_

# TECHNICAL DATA - CHASSIS TIGHTENING TORQUES

Screw connection, suction line	M14x1.5	45 Nm (33.2 lbf ft)	Loctite <sup>®</sup> 577
Screw, bottom shock absorber	M14x1.5	80 Nm (59 lbf ft)	Thread greased
Screw, top shock absorber	M14x1.5	80 Nm (59 lbf ft)	Thread greased
Nut, oil line	M16x1.5	25 Nm (18.4 lbf ft)	-
Nut, swingarm pivot	M19x1.5	130 Nm (95.9 lbf ft)	Thread greased
Screw, steering head	M20x1.5	12 Nm (8.9 lbf ft)	-
Bolt, front axle	M25x1.5	45 Nm (33.2 lbf ft)	-
Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)	Thread greased

### Brake fluid DOT 4 / DOT 5.1

#### According to

– DOT

#### Guideline

Use only brake fluid that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties. KTM recommends Castrol and Motorex<sup>®</sup> products.

#### Supplier

#### Castrol

- RESPONSE BRAKE FLUID SUPER DOT 4

## Motorex®

Brake Fluid DOT 5.1

## Coolant

#### Guideline

Use only suitable coolant (also in countries with high temperatures). Use of low-quality antifreeze can lead to corrosion and foaming.
 KTM recommends Motorex<sup>®</sup> products.

#### Mixture ratio

Antifreeze protection: -2545 °C (-13	50 % corrosion inhibitor/antifreeze
-49 °F)	50 % distilled water

## Coolant (mixed ready to use)

Antifreeze -40 °C (-40 °F)
----------------------------

#### Supplier

Motorex<sup>®</sup>

Anti Freeze

## Engine oil (SAE 10W/50)

#### According to

- JASO T903 MA (🕶 p. 200)
- SAE (🕶 p. 200) (SAE 10W/50)

#### Guideline

Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding
properties. KTM recommends Motorex<sup>®</sup> products.

Fully synthetic engine oil

#### Supplier

### Motorex®

Power Synt 4T

## Engine oil (SAE 5W/40)

#### According to

- JASO T903 MA (\* p. 200)
- SAE (\* p. 200) (SAE 5W/40)

#### Guideline

Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding
properties. KTM recommends Motorex<sup>®</sup> products.

Synthetic engine oil

#### Supplier Motorex®

#### Power Synt 4T

## Fork oil (SAE 5)

#### According to

– SAE (\* p. 200) (SAE 5)

#### Guideline

 Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends Motorex<sup>®</sup> products.

#### Supplier

#### Motorex®

Racing Fork Oil

## Hydraulic fluid (15)

#### According to

– ISO VG (15)

#### Guideline

Use only hydraulic oil that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties. KTM recommends Motorex<sup>®</sup> products.

### Supplier

#### Motorex®

– Hydraulic Fluid 75

## Shock absorber oil (SAE 2,5) (50180342S1)

#### According to

– SAE (🕶 p. 200) (SAE 2,5)

#### Guideline

 Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

## Super unleaded (ROZ 95 / RON 95 / PON 91)

#### According to

– DIN EN 228 (ROZ 95 / RON 95 / PON 91)

# **AUXILIARY SUBSTANCES**

#### **Chain cleaner**

#### Guideline

- KTM recommends **Motorex**<sup>®</sup> products.

### Supplier

## Motorex®

– Chain Clean

## Chain lube for road use

#### Guideline

KTM recommends Motorex<sup>®</sup> products.

#### Supplier

### Motorex®

- Chainlube Road

## Cleaning and preserving materials for metal, rubber and plastic

#### Guideline

- KTM recommends Motorex® products.

#### Supplier

### Motorex®

Protect & Shine

## High-luster polish for paint

#### Guideline

KTM recommends Motorex<sup>®</sup> products.

## Supplier

### Motorex®

Moto Polish

# **AUXILIARY SUBSTANCES**

### Long-life grease

#### Guideline

- KTM recommends **Motorex<sup>®</sup>** products.

### Supplier

Motorex®

- Bike Grease 2000

## Motorcycle cleaner

#### Guideline

- KTM recommends **Motorex®** products.

### Supplier

### Motorex®

- Moto Clean 900

## Universal oil spray

#### Guideline

- KTM recommends **Motorex**<sup>®</sup> products.

#### Supplier

Motorex®

Joker 440 Synthetic

# **STANDARDS**

## **JASO T903 MA**

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. With most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

## SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

Α
Accessories
Antifreeze
checking
В
Baggage
Battery
installing
removing
Blink code
engine control
Brake disc, rear checking
Brake discs, front
checking
Brake fluid
front brake, adding96 rear brake, adding101
Brake fluid level
front brake, checking
Brake light bulb changing

Brake linings         97           front brake, checking         97           rear brake, checking         102
Brakes         62           Braking         62
C
Chain checking
Chain tension         88           adjusting         88           checking         87           Chassis number         26

## Clutch

checking/correcting fluid level	93
Clutch lever	
basic position, adjusting	
Combination instrument	35
clock, setting	40
coolant temperature indicator	45
display	
display, ambient temperature	
function buttons	
indicator lamps	
kilometers or miles, setting	
<b>ODO</b> display	41

speed display
temperature units, setting
TRIP 1 display, setting/resetting
TRIP 2 display, setting/resetting       42         TRIP F display       43
warning of slippery roads44
Coolant draining
Coolant level checking
Cooling system
filling/bleeding
D
Display
E
Electric starter button       35         Emergency OFF switch       34
Engine
running in
Engine number
Engine oil adding

draining
Engine oil level
checking
Engine sprocket checking
Environment
F
Filler cap
closing
opening
Foot brake lever
free travel, checking
Fork70compression damping, adjusting70fork legs, bleeding81rebound, adjusting71spring preload, adjusting72
Fork part number
Front wheel
installing
Fuel tank
positioning
Fuel, oils, etc

## Fuse н Hand brake lever 30 Headlight adjustment **Headlight bulb** 48 Ignition curve Ignition key

## 

## K License plate lamp М Main fuse Motorcycle cleaning 0 **Oil filter** Oil screen **Oil screens**

Owner's manual 18

Ρ							
Parking							
Parking light bulb changing							
Passenger footrests							
Play in throttle cable adjusting							
Preparing for use after storage							
Protective treatment for winter operation							
R							

#### Rear hub shock absorber

checking	 	 	 	 1	.09
Rear sprocket checking	 	 	 	 	90
				1 1	
fuel	 	 	 	 	65
-				•••••	

## S

Seat
mounting
removing
Seat lock
Service
Service schedule
Shift lever
basic position, adjusting
basic position, checking
<b>Shifting</b>
Shock absorber
compression damping, general74
compression damping, high-speed, adjusting
compression damping, low-speed, adjusting
rebound damping, adjusting76
spring preload, adjusting77
Shock absorber part number
Side stand
Spare parts
<b>Starting</b>
Steering lock
<b>Stopping</b>
<b>Storage</b>
т

Tachometer																																					36	õ
Tachonielei	•	·	•	·	•	•	•	•	•	·	·	·	·	·	•	•	·	·	·	·	÷	÷	·	·	·	·	·	·	·	·	•	·	•	·	·	•	50	5

2	0	5

#### Tail lamp bulbs

changing
Technical data
chassis 185-187
chassis tightening torques 191-193
engine 179-180
engine tightening torques 181-184
fork
shock absorber 189-190
<b>Throttle grip</b>
Tire air pressure
checking
Tire condition
checking
<b>Tool set</b>
Transport
<b>Troubleshooting</b>
Turn signal bulb
changing
Turn signal switch
<b>Type label</b>
U
Use definition
V
View of vehicle
front left

rear right side		24
-----------------	--	----

W	
Warning of slippery roads	44
Warranty	8
Work rules	9



3211661en



KTM-Sportmotorcycle AG 5230 Mattighofen/Austria http://www.ktm.com 11/2010 Photo: Mitterbauer